



ComColorExpress IS1000C / IS950C

Utility Guide

 **CAUTION**

To ensure safety precautions, be sure to read the Setup Guide (separate manual) before using the product.

After reading this manual, keep it in handy for future reference.

Preface

Thank you for purchasing the ComColorExpress IS1000C / IS950C.

This product is a print controller that allows a RISO high-speed color printer to be used as a network-compatible PostScript3 printer. This unit allows various functions such as data output and printer monitoring to be used from Windows and Macintosh computers.

Organization of Instruction Manuals

There are three instruction manuals for this product.

- “Setup Guide”
This manual describes how to connect the IS1000C / IS950C and the installation procedures for the software that comes with this product.
- “Printer Driver Guide”
This manual describes specific functions of and the setup procedure for the printer driver.
- “Utility Guide” (This Manual)
This manual describes Console functions for checking the status of and managing this product through a network, and the software that comes with this product.

Read each of the manuals before using this product or when there is something you do not understand while using it.

Content of Instruction Manuals

Notes

- 1) Unauthorised reproduction of all or part of this manual is strictly prohibited.
- 2) Since there may be improvements to the product, the content of this manual may change in the future without notice.
- 3) RISO takes no responsibility for effects resulting from this manual or the operation of this product.
- 4) The illustrations included in this document depict the IS1000C model in most cases.

Copyrights

RISO and ComColorExpress are trademarks or registered trademarks of RISO KAGAKU CORPORATION in the United States and other countries.

Adobe, AdobePS, PostScript, PostScript3 and the PostScript logo are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States and/or other countries.

Macintosh and Mac OS are trademarks of Apple Inc.

Microsoft, Windows, Windows Vista and Windows Server are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

SOFHA is a registered trademark of SOFHA GmbH, Germany.

Other corporate names and/or trademarks are either registered trademarks or trademarks of each company, respectively.

Copyright © IS1000C / IS950C Manuals: 2016 RISO KAGAKU CORPORATION

Copyright © IS1000C / IS950C Software: 2006-2016 SOFHA GmbH, Germany

Contents

| | |
|---------------------------------------|---|
| Icons Used in This Manual | 5 |
| Terminology used in this manual | 5 |

Basic Operations **6**

| | |
|--|----|
| Opening the Screen..... | 6 |
| Overview of the RISO Console Screen | 7 |
| Logging in to the Print Controller | 9 |
| How to Log In | 9 |
| Functions for Guest Users / General Users..... | 10 |
| Creating a job | 11 |
| Creating Archived Jobs | 14 |
| Printing Jobs..... | 15 |

Other Operations **18**

| | |
|---|----|
| Queues | 18 |
| Checking Queue Settings | 19 |
| Queue management..... | 19 |
| Jobs (Job manager)..... | 20 |
| Checking Job Status..... | 20 |
| Copying a Job to Another Queue | 21 |
| Moving a Job to Another Queue | 21 |
| Deleting a Job..... | 22 |
| Cancelling a Processing / Waiting Job | 22 |
| Rearranging Job Display Order | 23 |
| Displaying Thumbnails of a Job (Job Preview)..... | 23 |
| Viewing / Editing Job Details | 24 |
| Archived Jobs | 37 |
| Editing Archived Jobs | 37 |
| Merging Multiple Archived Jobs..... | 41 |
| Merging Pages from Multiple Archived Jobs | 42 |
| Saving Archived Jobs to the Computer | 43 |
| Importing an Archived Job from the Computer..... | 45 |
| Checking Printer Status | 46 |
| General..... | 46 |
| Paper trays | 46 |
| Output trays | 47 |
| Installable options..... | 47 |
| Consumables..... | 48 |
| Selecting Languages | 49 |

| | |
|---|-----------|
| Administrator Settings | 50 |
| Administrator | 50 |
| How to Log In | 50 |
| Available functions for administrator..... | 50 |
| Detailed Settings of the Print Controller | 51 |
| General..... | 52 |
| Communication settings | 53 |
| IPSec Settings | 55 |
| User management | 58 |
| Job settings | 60 |
| RIPs in network | 62 |
| Time settings | 64 |
| Monitor settings | 65 |
| Backup..... | 66 |
| SNMPv3 | 68 |
| HDD backup | 69 |
| Customization Settings..... | 74 |
| Custom forms | 75 |
| Custom paper sizes..... | 76 |
| PCL tray mapping..... | 77 |
| Barcode area | 78 |
| Color calibration..... | 80 |
| Profile management | 81 |
| Uploading profiles [Upload profile...]. | 82 |
| Font management | 83 |
| Reports | 84 |
| Log settings | 85 |
| Checking the System Events Log..... | 87 |
| Checking Accounting Information..... | 88 |
| Managing Custom Queue..... | 90 |
| Creating New Queues [New queue] | 90 |
| Deleting Custom Queues [Delete queue] | 91 |
| Changing Detailed Settings of Queues [Queue details...] | 92 |
| Stopping Queue Processing [Stop] | 95 |
| Resuming Queue Processing [Start] | 95 |
| Rebooting the Print Controller | 96 |
| Shutting Down the Print Controller | 96 |

Using the Included Utility Software 98

Utility Software..... 98

Using the RISO Management Tool..... 99

 Starting the RISO Management Tool 99

 Basic screen 99

 Searching for Print Controllers on the Network 100

 Displaying Print Controller Settings 100

 Adding Print Controllers to the List 101

 Deleting Print Controllers from the List 101

 Starting Up Print Controllers 102

 Displaying Latest Status 102

 Starting Up the RISO Console..... 103

Using SMAP (Windows only)..... 104

 Starting SMAP 104

 Direct Printing by SMAP 105

 Dragging and Dropping Files on the SMAP Icon on the Desktop..... 107

Appendix 108




Feature Restrictions 108

Troubleshooting..... 109

Index..... 110

Icons Used in This Manual

Functions, operations and cautions are described as follows in this manual.

| | |
|--|---|
| Important! | describes items where care is necessary or where there are prohibitions. |
| Note | describes items where there is particularly helpful information and ones where there is something that should be known. |
|  | indicates the title and page of an item that should be referred to and thoroughly understood. When the reference is to another manual, the name of the manual will also be noted. |
|  WARNING  Caution | are safety cautions. "Safety Precautions" are described in a separate manual, "Setup Guide". Be sure to read them before using this product. |

Terminology used in this manual

◆ Job

The original data sent from the computer is not directly sent to the printer but temporarily stored in the print controller. The data in this status is called a "job".

◆ Queue

The jobs stored in the print controller are lined up in a "window" for executing print processing. Various settings on how to process the sent jobs can be registered in this "window" in advance. This "window" is called a "queue".

◆ Log in

To create your own jobs, a login ID and password are required. The act of inputting such information in order to access network and device is called "login".

Basic Operations

Accessing the ComColorExpress IS1000C / IS950C from your web browser enables you, among other things, to utilize the job manager for output data, and to monitor the printer. This software is called “RISO Console”.

The software makes available a variety of convenient functions, including the **[Create new queue]** function that reduces the time taken to set printing conditions, and the **[Hold queue]** function that enables quick printing by simply calling up data uploaded in advance.

The basic functions and the operation method of the RISO Console are explained here.

- For details on functions available to guest users and general users, see “Other Operations” p.18.
- For details on functions for the administrator, see “Administrator Settings” p.50.
- For user authority (guest user / general user / administrator), see “Logging in to the Print Controller” p.9.

Opening the Screen


1 Launch your Web browser.

See your computer operating manual or Help.

2 Input the IP address in the address bar of the URL.


In the address bar, enter `http://`the IP address of the printer controller.

The administrator sets the IP address. Enter the IP address (i.e. 169.254.250.223) confirmed by the administrator.



3 Press the [ENTER] key.

The screen of the RISO console is displayed.




Note:

- We recommend creating a desktop shortcut as an easy way of displaying the RISO Console screen.
- When accessing to the print controller by https (encrypted communication), enter `https://`(the IP address of the printer) in the address bar.
It is also possible to access the print controller automatically by https (encrypted communication). p.53
- The RISO Console screen can be also displayed from **[WWW]** on the RISO Management Tool. p.103

Overview of the RISO Console Screen

The screen layout of the RISO Console is explained below.



1) Menu

Displays submenu by moving the mouse pointer over each menu button.

2) Login information input area

Logs in by entering the login ID and the password.

3) Message display area

Displays confirmation messages and error messages related to the operation on the Console screen.

4) Job / Queue selection button

Clicking the Queue or Job button switches to the job list of the selected queue or job type.

Note:

- Clicking the **[My jobs]** button after logging in displays only your own jobs.

5) Status display area

Displays the current status of the printer and the print controller.
Click to monitor the status of the printer (the RISO Console screen for the print controller is displayed).

6) Job list

The jobs in the print controller are listed according to the processing status.

Note:

- For details on icons displayed in the job list and job/queue information display, see "Icons" p.8.

Jobs in the queue

Displays a list of jobs in the selected queue or jobs of the selected job type.

Waiting jobs

Displays a list of jobs waiting in the print controller.




Active jobs

Displays the jobs undergoing print processing while being processed by the print controller.

Finished jobs

Displays a list of finished, cancelled, and failed jobs.

Note:

- Clicking  on the upper-right corner of each list box minimizes the list box. Clicking  when the list box has been minimized returns the list box to the normal size. Clicking  on the upper-right corner of the **[Jobs of]** list box closes the list box.

7) Job / Queue information display

When the queue has been selected, the function icons and the general information of the selected queue are displayed.

When a job has been selected in the job list, the function icons and the general information of the selected job are displayed.

Icons

The following icons are used in the job list and job/queue information display.



: Used to delete a job [p.22](#)



: Used to print a job [p.15](#)



: Used to cancel a job (becomes a job being processed) [p.22](#)



: Used to edit a job or queue [p.24](#), [p.92](#)



: Used to view and confirm queue settings [p.19](#)



: Used to copy a job [p.21](#)



: Used to move a job [p.21](#)



: Used to upload a job [p.11](#)



: Used to delete a custom queue [p.91](#)



: Used to stop a queue (for normal queues only) [p.95](#)



: Used to resume a queue* (for normal queues only) [p.95](#)

* Displayed after you click  to stop a queue.

Logging in to the Print Controller

There are the following three ways to log in to the print controller and three kinds of access authority.

- Without logging in (Guest user): The print controller is used without logging in. Only certain functions can be used.
- General user: Login using a “Login” (ID) and “Password” registered by the administrator. The general user has more authority over his / her own jobs than the administrator. However administrator settings are not available.
- Administrator: Login using an administrator “Login” (ID) and “Password”. The administrator can configure the administrator settings, such as print controller settings. [p.50](#)


How to Log In

Enter the “Login” (ID) and “Password” in the input area, and click the [Log in] button.


The “Login” (ID) and “Password” must be registered in the RISO Console by the administrator in advance.

[p.58](#)

For details, confirm with your network administrator.



To log out, click the **[Log out]** button.



Functions for Guest Users / General Users

When using the RISO Console without logging in (guest user) or logging in as a general user, the following functions are available on the RISO Console.

- Viewing detailed settings of the print controller [p.51](#)
- Viewing how job processing is distributed over the network by the print controller (load balancing settings) [p.62](#)
- Checking printer status [p.46](#)
- Checking the settings of the queue [p.19](#)
- Uploading jobs [p.11](#)

Note:

- When **[Enforce login]** has been set by the administrator using “User management” ([p.58](#)), all the functions except for logging in are not available.

When **[Others can see jobs]** has been set by the administrator using “User management” ([p.58](#)), the following functions are available for both guest users and general users.

- Printing a job [p.15](#)
- Viewing the list of jobs [p.20](#)
- Viewing detailed settings of jobs [p.24](#)
- Copying jobs [p.21](#)
- Changing job settings, moving jobs* [p.21](#), [p.24](#)
- Cancelling a waiting job* [p.22](#)
- Importing archived jobs [p.45](#)
- Feeding back archived job [p.43](#)
- Merging archived jobs [p.42](#)
- Creating an archived job from a held job* [p.14](#)
- Downloading a print-format file exported via “Create Print Data” (creating a PRN file) [p.79](#)

* Only jobs without an owner’s name

Note:

- When **[Others can see jobs]** is not set and you are logged in as a general user, these functions are available for your own jobs.

When you are logged in as a general user, the following functions are available for your own jobs.

- Editing job settings [p.24](#)
- Deleting the job [p.22](#)
- Moving the job [p.21](#)
- Cancelling job processing [p.22](#)
- Creating an archived job from a held job [p.14](#)


Creating a job

Normally jobs are created (sent to the controller) using the print driver, however, they can also be added directly to a queue using the Console, as explained here.

Files with the following extensions can be used to create a job directly using the Console.


File extensions: pdf, ps, tiff (tif), pcl, zip

- 1 Click the queue button for adding the job from the Job / Queue selection buttons (on the left side of the screen).





Note:


- When the target queue button is not displayed in the screen, click the **[More queues...]** button, and select a queue from the list of queues. The **[More queues...]** button is displayed if the administrator has created new queues.



The button of the selected queue is displayed.




- 2 With no job selected, click  of the job / queue information display (on the right side of the screen).




- 3 Select the file to add.

After clicking the **[Browse]** button, select the file on the file selection dialog box, and then click the **[Open]** button.



4 Click the [Upload job] button.



The job is added to the queue.



Note:

- The job can also be added to the queue by moving the mouse pointer over the **[Queue]** menu button and then clicking **[Upload job...]** in the displayed submenu.

Hotfolder


This function enables you to directly access queues in the print controller on the network. Queues are displayed as folders. Therefore, the file is printed at the processing conditions set in the desired queue by simply dragging and dropping it into that queue. The file can be printed or stored in the Hold queue without opening the application.

Note:


- The file formats that can be printed are as follows.
PostScript file, PDF file, TIFF file
Files that have no owner set for them cannot be printed when the printer mode is set to **[Required]** for the printer's administrator setting (login setting).
- The SMB protocol and FTP protocol are supported for accessing the hotfolder.

- 1) Open Windows Explorer.
- 2) Enter \\(the IP address of the IS1000C / IS950C)\hotfolder (i.e. \\169.254.250.223\hotfolder) or ftp://(the IP address of the IS1000C / IS950C)/queue (i.e. ftp://169.254.250.223/queue) in the address bar. The hotfolder is displayed.

(For SMB)




(For FTP)



Note:

- We recommend creating a desktop shortcut as an easy way of displaying the hotfolder.

- 3) Drag and drop the file to print or hold on the desired queue.



The processing set in the queue is performed.

Creating Archived Jobs

In order to create archived jobs, the following methods are available.

- When printing original data from the computer, set **[Destination]** to **[Archive]** or **[Print & archive]** in the **[Workflow]** screen of the printer driver.
For details, refer to the separate manual, “Printer Driver Guide”.
- For jobs sent to the print controller, set **[Destination]** to **[Archive]** or **[Print & archive]** in the **[Workflow]** screen of the job details screen. [☞ p.34](#)
- By merging the existing archived jobs, create a different archive job. [☞ p.42](#)

Note:

- The Secure print function cannot be set with data to be output to an archive. Data output to an archive can be freely accessed from the RISO Console. It is recommended not to output confidential documents to archives.
- When printing an archived job, settings for the following functions cannot be changed. To change the settings, recreate the archive job.


| Function name | Setting screen name | Page |
|--|---------------------|------------------------|
| Page size | Basic | ☞ p.25 |
| Orientation | | |
| Paper type | | |
| Color output mode | | |
| Output size (Scale to fit) | Layout | ☞ p.27 |
| Mixed output size | | |
| Zoom | | |
| Imposition (Imposition direction) | | |
| Multi-up | | |
| Binding margin (Auto-reducing) | | |
| Creep compensation | | |
| Image rotation | Trays | ☞ p.28 |
| Booklet | Finishing | ☞ p.29 |
| Resolution (dpi) | Image | ☞ p.30 |
| Line smoothing | | |
| Gamma control | | |
| Barcode Area Definition (Barcode Area Proof) | | |
| Destination | Workflow | ☞ p.34 |
| Secure print | | |
| Job splitting | | |
| Job delegation | | |
| Color profile | Color | ☞ p.35 |
| Rendering intent | | |

Printing Jobs

You can print jobs that have been held, archived, etc.


1 Click the button to which the job to be printed is registered from the Job / Queue selection buttons (on the left side of the screen).

- To print a job registered in the Hold queue, click the **[Hold jobs]** button.
- To print an archived job, click the **[Archive jobs]** button.
- To reprint a failed job, this operation is not necessary.



2 Select the job to print from the job list.

- To print a job registered in the Hold queue, select the job from the job list in the Hold queue.
- To print an archived job, select the job from the list of Archived jobs.
- To reprint a failed job, select the job from the list of Finished jobs.



The information of the job is displayed in the Queue / Job information display (on the right side of the screen).

Note:

- The following operations are available here.
 - Viewing / Editing job details
 - Printing a job
 - Reprinting a job
 - Copying a job (to another queue)
 - Moving a job (to another queue)
 - Deleting a job
 - Cancelling a waiting / processing job
 - Rearranging job display order
 - Displaying thumbnails of a job (job preview)

3 Change the job settings if necessary.

For details, see “Viewing / Editing Job Details”
p.24.

Note:

- When an archived job is selected, click **[Overview...]** in the job preview to edit, delete pages, etc. For details, see “Editing Archived Jobs”
p.37.


4 Click of the Job / Queue information display (on the right side of the screen).



Printing will start.

Note:

- Jobs can also be printed by moving the mouse pointer over the **[Job]** menu button and then clicking **[Print]** from the displayed submenu.
- Jobs can also be printed by clicking the print icon in the job list.





Other Operations

Queues

There are two types of queues - Normal and Hold. Two types of queues - “Normal” and “Hold” - are prepared for the print controller in advance. An arbitrary queue can be added by the administrator (Custom Queue).

◆ Normal queue:

This queue is for actually printing or storing jobs as archive jobs. The jobs sent to this queue from the computer are processed in chronological order.

◆ Hold queue:

This queue is for storing jobs. The jobs sent to this queue from the computer are stored in the print controller. To process jobs stored in the Hold queue, give commands such as printing a job, using the RISO Console. Storing original data that are frequently used or shared documents in the Hold queue enables to print them without opening the application and giving the command to print for every job from the RISO Console screen.

Important!:

- We can take no responsibility for data loss occurring in this product's internal hard disk that results from use of this product. We recommend regularly making backups to protect data.
- You can backup the setting information and job data saved on this product via administrator settings. For details, see “Backup” [p.66](#).

Note:

- “Normal” and “Hold” queues are pre-registered at the factory. These queues cannot be deleted. Moreover, the following settings can be changed.
 - Normal: Queue code, priority, direct port, prechecking setting
 - Hold: Queue code, prechecking setting
- The administrator can register various settings for processing jobs sent from the computer in the print controller as a Custom Queue. [p.90](#)
By registering frequently used print settings as a Custom Queue, jobs can be printed using the saved settings by sending the data to the Custom Queue.

Checking Queue Settings


The processing conditions set for each queue can be checked as follows.


- 1 Select a queue to check by clicking the Job / Queue selection button (on the left side of the screen).




Note:

- When the target queue button is not displayed in the screen, click the **[More queues...]** button, and select a queue from the list of queues. The button of the selected queue is displayed.

- 2 With no job selected, click  of the job / queue information display (on the right side of the screen).



A details screen of the queue is displayed. Clicking the setting group icons at the top of the screen switches the details screen.



Note:

- A details screen of the queue can be also displayed by moving the mouse pointer over the **[Queue]** menu button and then clicking **[Queue details...]** in the displayed submenu.
- For displayed items, see “Changing Detailed Settings of Queues” [p.92](#).

- 3 After checking the setup, click the **[Close]** button.

Queue management

The administrator can operate queues as follows. [p.90](#)

- Create new queues [p.90](#)
- Deleting Custom Queues [p.91](#)
- Edit settings for the queue [p.92](#)
- Stop / Resume queue processing [p.95](#)

Jobs (Job manager)

The original data sent from the computer to the print controller is stored in the queue of the print controller as a job. Various operations can be performed using the RISO Console such as job copying, moving, deletion, queue setup viewing and editing (The operations that are available depend on whether you are the job owner or not).

Job ownership

The user who sends a job to the print controller is the owner of that job. The owner of the job can operate the created job (copy, move, delete, edit settings, etc.) in various ways. Operation by other users than the job owner may be restricted by the administrator.


Note:

- In the Hold queue of the print controller, three sample jobs are stored at the factory -PCL Font Sample Page, PS Font Sample Page, and Settings Page. These sample pages cannot be deleted.


Checking Job Status

- 1 Click the queue button in which the job is stored from the Job / Queue selection button (on the left side of the screen).

A list of jobs stored in the queue is displayed.



- 2 Click the job you want to check in the job list.



The information of the job is displayed in the Job / Queue information display (on the right side of the screen).

The following operations are available here.

- Viewing / Editing job details
- Printing a job
- Reprinting a job
- Copying a job (to another queue)
- Moving a job (to another queue)
- Deleting a job
- Cancelling a waiting / processing job
- Rearranging job display order
- Displaying thumbnails of a job (job preview)

Note:

- Functions that cannot be operated according to job authority or administrator settings are greyed out and cannot be selected. For details on user authority for each function, see “Functions for Guest Users / General Users” p.10.

Copying a Job to Another Queue

1 Select the job to copy from the job list.


For details, see “Checking Job Status” p.20.

2 Click of the Job / Queue information display (on the right side of the screen).



3 Select the destination queue to copy.

When the queue button is clicked, the job is added to the destination queue.



Moving a Job to Another Queue


1 Select the job to move from the job list.

For details, see “Checking Job Status” p.20.

2 Click of the Job / Queue information display (on the right side of the screen).



3 Select the destination queue to move.



4 Click the [Yes] button in the confirmation dialog box.

After clicking the [Yes] button in the confirmation box, the job is deleted from the original queue and added to the destination queue.


Note:

- To cancel job moving, click the [No] button in the confirmation dialog box.

Deleting a Job

1 Select the job to delete from the job list.


For details, see “Checking Job Status” p.20.

2 Click  of the Job / Queue information display (on the right side of the screen).



Note:

- The job can be also deleted by clicking the deletion icon in the job list.




3 Click the [Yes] button in the confirmation dialog box.

Note:

- To cancel job deletion, click the [No] button in the confirmation dialog box.

Cancelling a Processing / Waiting Job


1 Click the job you want to cancel from the [Active jobs] or [Waiting jobs] list.

2 Click  of the Job / Queue information display (on the right side of the screen).



Note:

- The job can be also cancelled by clicking the cancel icon in the [Active jobs] or [Waiting jobs] list.




3 Click the [Yes] button in the confirmation dialog box.

Note:

- To cancel job cancellation, click the [No] button in the confirmation dialog box.

The information of the cancelled jobs is displayed in the [Finished jobs] list.



Note:

- Cancelled jobs can be reprinted or deleted. You can select the job from the [Finished jobs] list, and print or delete it in the same way as normal jobs.

Rearranging Job Display Order

The job list is normally displayed with the first job to process at the bottom. (The order of actual processing of jobs does not change.)

When you click the same item header repeatedly, the order switches between ascending order and descending order.


When you return the display of the job list to the actual processing order, arrange **[ID]** in descending order (chronological order with the newest job first).

| ID | Name | Owner | Pages | Queue | Status |
|----|------------------|---------|-------|-------|---------|
| 12 | Document_001.pdf | Sales01 | 5 | Hold | Inqueue |
| 11 | Document_002.pdf | Sales01 | 18 | Hold | Inqueue |
| 9 | Document_002.pdf | Sales01 | 18 | Hold | Inqueue |


Displaying Thumbnails of a Job (Job Preview)

1 Select the job from the job list in the queue.

A piece of the job thumbnail is displayed in the Job / Queue information display (on the right side of the screen).



2 Click the job preview image.



Thumbnails are displayed of all pages.



3 After checking the setup, click the [Close] button.

Viewing / Editing Job Details

1 Select the job to view / edit from the job list.


For details, see “Checking Job Status” p.20.

2 Click of the Job / Queue information display (on the right side of the screen).




The detailed settings screen for the job is displayed.

Detailed settings screen for the job (Editing screen)



Note:

- When there is no authority on editing and operating the job,  is displayed. By clicking this icon, you can view detailed settings of the job. (Settings cannot be changed.)

3 Change the job processing settings if necessary.

When you click the icon at the top of the screen, the screen will switch.

[Ok]: Click to save setting changes and end editing.


[Apply]: Click to save setting changes and continue editing.

[Cancel]: Click to cancel setting changes and end editing.

For an overview of settings on each screen, see the next page onward.

[Basic] Screen

Configures settings for normal printing such as page size, orientation and paper type.



Settings

- | | |
|--|---|
| <p>1) Page size Displays the size of the original.</p> <p>2) Orientation Selects the orientation of printing the original.</p> <p>3) Input tray*¹ Selects the tray holding the paper for printing.</p> <p>4) Paper type Selects the paper type.</p> | <p>5) Color output mode Selects color or single-color (black, cyan, or magenta) printing.</p> <p>6) Staple mode*² Staples printed paper.</p> <p>7) Punch mode*³ Punches holes in printed paper.</p> <p>8) Quick print settings Click a button for frequently used setting for originals to be printed. Clicking the button closes the screen, and starts processing according to the selected layout.</p> |
|--|---|

*1 Not available when the printer has no multi-tray paper feeder.

*2 Staple mode is available when a Multifunction Finisher or Face Down Offset Tray is connected.


*3 Punch mode is available when a Multifunction Finisher is connected.

Note:

- For details of settings, refer to the separate manual, "Printer Driver Guide".

[General] Screen

The outline information and basic settings are displayed for the job.




Information displayed / Settings

- 1) Name***
Displays the name of the job.
- 2) Type**
Displays the type of job.
The types of jobs that can be used are as follows:
PostScript(PS), PCL, PDF, TIFF, ASCII,
PPML (as option)
- 3) Status**
Displays the processing state of the job.
- 4) PC name**
Displays information on the job source (the name or IP address of the computer).
- 5) Owner***
Displays the owner name of the job.
- 6) Source**
Displays information on the port through which the job has been received.
- 7) Pages**
Displays the number of pages in the job.
- 8) Print pages***
Specifies the pages to print.
- 9) Copy count***
Specifies the number of copies to print.
- 10) Pages to print**
Displays the total number of pages of the job (the number of pages of the original x the number of copies).
- 11) Prechecking***
Displays the data precheck (data quality check before output) setting.
Clicking the **[Restart prechecking...]** button performs the data precheck processing. [p.93](#)

* If you have the authority, it is possible to change or process the file.

[Layout] Screen

Configures the imposition method and enlargement / reduction rate for printing.



Settings

1) Duplex

Selects whether or not to perform duplex printing.

2) Page size*1

Displays the size of the original.

3) Orientation*1

Selects the orientation of printing the original.

4) Image rotation

Sets the print orientation of the original relative to the paper.

5) Mixed output size*2

If the size of the original varies from page to page, you can print each page on appropriately sized paper.

6) Output size

Selects the paper size for printing.

7) Scale to fit

Places a checkmark in order to print the original data with its size automatically enlarged / reduced to fit the output paper size.

8) Zoom

Specifies the enlargement / reduction rate for printing.

9) Imposition

Selects the type of imposition.

10) Imposition direction

Specifies for the arrangement sequence of output pages.

11) Multi-up

If [Multi-up (Plural)] is selected at [Imposition], set the arrangement of pages and the number of pages per sheet for imposition.

12) Binding margin

Sets the binding margin width.

13) Auto-reducing

When a checkmark is placed, any image that is not included in the image area because of the margin width will be automatically reduced so that the image is included in the image area of the paper.

14) Creep compensation

Sets the "Creep compensation value", which changes the binding margin in relation to the outer and inner pages.

*1 The settings configured for [Page size] and [Orientation] via the [Basic] screen are applied.


*2 [Mixed output size] cannot be used for a printer with no multi-tray paper feeder, or when using a High Capacity Stacker.

Note:

- For details of settings, refer to the separate manual, "Printer Driver Guide".

[Trays] Screen

Selects the tray used when printing.



Settings

- 1) Input tray*1*5**
Selects the tray holding the paper for printing.
- 2) Tray selection per page*5**
You can select a different tray for each page.
- 3) Paper type*1**
Selects the paper type.
- 4) Output tray*2**
Specifies the destination tray.
- 5) Output face*3**
Selects whether to output pages face-up or face-down to the selected tray.
- 6) Continuous output*4**
If the output tray becomes full while printing, another output tray is used automatically.
- 7) Collate**
Selects whether multiple pages are printed as sets of pages, or printed in groups of individual pages.
- 8) Reverse order**
Prints originals in reverse order.
- 9) Slip sheet*5**
Inserts a sheet of paper from a tray different to the tray holding the paper being printed as a slip sheet.
- 10) Slip sheet tray*5**
Selects the tray containing paper to be used for job separation sheets.

*1 [Input tray] and [Paper type] are determined by the settings in the [Basic] screen.

*2 This function is available when a Multifunction Finisher, Auto-control Stacking Tray, Wide Stacking Tray or High Capacity Stacker is connected.

*3 This function is available when a Multifunction Finisher or High Capacity Stacker is connected.

*4 This function is available when a Multifunction Finisher, Auto-control Stacking Tray or High Capacity Stacker is connected.


*5 Not available when the printer has no multi-tray paper feeder.

Note:

- For details of settings, refer to the separate manual, "Printer Driver Guide".

[Finishing] Screen

Configures paper output settings such as collating.



Settings

- 1) Finishing side*1**
Specifies the finishing side for stapling or hole-punching.
- 2) Staple mode*2*5**
Staples printed paper.
- 3) Simplex Print Speed Priority*1**
Outputs stapled simplex pages face-up when you want to prioritize processing speed.
- 4) Punch mode*1*2**
Punches holes in printed paper.
- 5) Enable Subset Finishing*7**
Appears for jobs created by using a subset finishing application.
- 6) Print via duplex path**
Outputs a subset finishing job via duplex path.
A job will output without stopping even with a combination of simplex and duplex printing.
- 7) Imposition*3**
Selects the type of imposition.
- 8) Booklet fold mode*4**
Outputs booklets with two folds.
- 9) Separate books**
Splits a booklet into multiple books when making a booklet.
- 10) Booklet cover*6**
Prints and outputs cover pages and other pages separately.
This function is useful for printing the covers onto paper that is different with the paper of the body of the original.
- 11) Fold mode*4**
Outputs paper with 2 folds.
- 12) Folding direction**
Selects a paper folding direction.
- 13) Offset output pages*5**
Outputs paper at an offset position for each printing set.
- 14) Header page**
Prints a sheet with a job name / owner name, etc. to discern who printed.
- 15) Front cover, Back cover*6**
Selects the tray containing paper to be used for covers.
From the selected tray, the front cover is output before the first page of the original, and the back cover is output after the last page of the original.

*1 This function is available when a Multifunction Finisher is connected.

*2 [Staple mode] and [Punch mode] are determined by the settings in the [Basic] screen.

*3 [Imposition] is determined by the settings in the [Layout] screen.

*4 This function is available when a Multifunction Finisher's booklet-making function is activated.

*5 This function is available when a Multifunction Finisher or Face Down Offset Tray is connected.

*6 Not available when the printer has no multi-tray paper feeder.

*7 You can use PlanetPress, SVF, or other applications to output jobs for which settings vary by page.

Note:

- For details of settings, refer to the separate manual, "Printer Driver Guide".

[Image] Screen

Adjusts settings such as the resolution, color output mode, density and contrast of images.



Settings

- | | |
|--|---|
| <p>1) Color output mode* Selects color or single-color (black, cyan, or magenta) printing.</p> <p>2) Resolution Sets the image quality (resolution).</p> <p>3) Screening Selects the method of half-tone processing.</p> <p>4) Screen width Sets the screen width (line per inch).</p> <p>5) Draft Prints while saving ink via error diffusion.</p> <p>6) Envelope Processing Prevents blurring and fine errors when printing images on envelopes.</p> <p>7) Line smoothing Selects the degree of line smoothing.</p> | <p>8) Print density Adjusts the print density.</p> <p>9) Brightness Adjusts the density of images.</p> <p>10) Contrast Adjusts the contrast of images.</p> <p>11) Cyan, Magenta, Yellow, Black Adjusts the gamma level for each color.</p> <p>12) Barcode Area Definition Adjusts the print density in the specified barcode print area so that the barcode can properly be read. Before using [Barcode Area Definition], it is necessary to register the barcode print area in advance. For details, see “Barcode area” p.78.</p> <p>13) Barcode Area Proof Previews the print area specified by [Barcode Area Definition]. The specified area is shaded in the print.</p> |
|--|---|


* If you set **[Color output mode]** in the **[Basic]** screen, the setting is applied here.

Note:

- For details of settings, refer to the separate manual, “Printer Driver Guide”.

[Forms] Screen

Selects a form (archived job) registered in the print controller and prints output data overlaid on a form.



Settings

1) Print pattern

Sets whether or not to print a form (archived job) onto the same face as output data.

2) Print face

Selects whether to print a form (archived job) onto the front side or the back side when **[Overlay alternating (Long edge)]** / **[Overlaying alternating (Short edge)]** or **[Overlay alternating + each page (Long edge)]** / **[Overlaying alternating + each page (Short edge)]** is selected.

3) Front/Back separately

Specifies and prints different forms (archived jobs) for each side when duplex printing.

4) Priority layer

Selects whether to prioritize form or output data when **[Overlay each page]**, **[Overlay alternating + each page (Long edge)]**, or **[Overlay alternating + each page (Short edge)]** is selected.

5) Form 1 (all pages or front)

Selects the form (archived job) printed on the front side or both sides of the output data.

6) Form 2 (back)

Selects the form (archived job) printed on the back side the output data.

7) Prepend

Selects the form (archived job) added before the output data.

8) Append


Selects the form (archived job) added after the output data.

Note:

- For details of settings, refer to the separate manual, "Printer Driver Guide".
- Forms are registered from archived jobs stored in the print controller by the administrator. "Custom forms" p.75

[Annotation] Screen

Allows you to add header or footer text to output data that is printed.



Settings

1) Annotation

Prints the page number or a common string of text (such as a user name) to the left / middle / right at the bottom / top of the page.

2) Start number

When inserting page numbers, specify the page number that will appear on the first page that has a page number.

3) Print start page

When inserting page numbers, specify the page number of the first page that will be numbered.

4) Insert page number

You can select where the page number will appear.

5) Insert total pages

You can select where the total number of pages will appear.

6) Transparency

Makes the print area transparent.

7) Print first page only

You can select to have the entered number of pages or text appear on the first page only.

8) Font

Specify the header/footer (text, page number) font. You can select from the fonts installed on the print controller.

9) Font size

Specify the header/footer (text, page number) font size.

10) Insert font


Insert Font and Font size information.

Note:

- For details of settings, refer to the separate manual, "Printer Driver Guide".

[Image shift] Screen

Adjusts the vertical and horizontal margins of the original's images.



Settings

1) Horizontal shift

Adjusts the print position horizontally between -254 mm (-10") and 254 mm (10").

2) Vertical shift

Adjusts the print position vertically between -254 mm (-10") and 254 mm (10").

3) Shift front/back separately

When duplex printing, both front and back sides can be adjusted independently.

4) Horizontal shift back side

Adjusts the print position on the back side horizontally between -254 mm (-10") and 254 mm (10").

5) Vertical shift back side

Adjusts the print position on the back side vertically between -254 mm (-10") and 254 mm (10").

6) Print position


Selects a standard position allocated to the original image on the paper.

Note:

- For details of settings, refer to the separate manual, "Printer Driver Guide".

[Workflow] Screen

Configures settings for the output destination of the original, and output operation and notification method.



Settings

1) Destination

Selects whether data sent from the computer is printed onto sheets, or is stored as an archived job in the print controller. You can also create a PRN file for use with the Barcode Area Definition Software.

2) Secure print

A security code is assigned to the job. When **[Hide job name]** is checked, the job name will not be displayed in the job list.

3) Print and pause

Prints one page or one set only, and enables you to check the printed sheet(s) of paper.

4) Job splitting

Splits one job into multiple jobs.

5) Job delegation

When several print controllers of the same model are connected on the network, jobs are delegated to each print controller for processing.

6) Send E-mail

Sends a job status email message to a specified email address.

7) Comment

Displays comments entered in the **[Comment]** area of the printer driver's **[Workflow]** screen. Comments can also be entered here.


Note:

- For details of settings, refer to the separate manual, "Printer Driver Guide".

[Color] Screen

Some image data colors may not be reproducible.

In this case, 4 types of rendering intent and color profiles are used, and mapping (image compression) and color conversion is performed to reproduce colors as close to the original as possible or natural color tones.



Settings

1) RGB: No profile / Map RGB to CIE

An RGB input profile can be selected.

2) CMYK: Map CMYK to CIE / DeviceLink / No profile

A CMYK input profile or DeviceLink profile can be selected.

3) Output profiles

[Auto] or output profiles added arbitrarily can be selected.

4) Pure black

Selects whether or not to reproduce grayscale.

5) Max drops

Sets the maximum amount of ink drops.

6) Rendering intent


Selects one of four different types of color conversion to reproduce colors.

Note:

- When [Output profile] is set to [Auto], [Rendering intent] cannot be selected.
- For details of settings, refer to the separate manual, "Printer Driver Guide".

[Logging] Screen

Displays records of print controller processing for the selected job.



Information displayed

1) Logging

Displays the time when each processing was executed, processing conditions, and detailed information.

2) PostScript output

Displays information such as error codes that occurred during PostScript conversion.

Archived Jobs

The print controller makes it possible to create and store the ripped data (archived jobs). The following operations can be performed with that data.


- Printing
Stored archived jobs can be repeatedly printed from the RISO Console. Printing jobs from the archive shortens the time required for ripping.
- Feedback
Downloads as image data
Downloads archive data to a computer
- Merge
- Use as forms

Editing Archived Jobs

- 1 Click the **[Archive jobs]** button from the **Job / Queue** selection button (on the left side of the screen), and select the job to edit from the list of archived jobs.

For details, see steps 1 and 2 in “Printing Jobs” p.15.

- 2 Click **[Overview...]** in the **Job preview**.



Thumbnails are displayed of all pages.



Note:

- The preview screen can be also displayed by moving the mouse pointer over the **[Job]** menu button and then clicking **[Overview...]** in the displayed submenu.
- Double-clicking the page opens an enlarged image of the page in a different screen.

3 Edit the archive data in the preview screen.

The following operations are available.

- Moving pages [p.38](#)
- Copying pages [p.39](#)
- Inserting blank pages [p.39](#)
- Deleting pages [p.40](#)

Note:

- Pages can be copied from multiple archived data and merged. For details, see “Merging Pages from Multiple Archived Jobs” [p.42](#).

4 Save the edited archived data.


- 1) Click the **[Save changes]** button on the preview screen.
- 2) Enter the new job name, and click the **[OK]** button.
After the job is processed, it is added to the list of archived jobs.

Note:

- To not save the edited archived data, click the **[Close]** button on the preview screen, and click the **[Yes]** button in the confirmation dialog box.

Moving Pages

Select the page on the preview screen of the archived job, and drag and drop the page in the location you want to move it to.



The selected page is moved to the location in front of the selected page.




Copying Pages [Duplicate]

- 1 Select the page to copy on the preview screen of the archived job.
- 2 Click [Duplicate].



The copied page is added after the original page.



Adding Blank Pages [Insert blank page]

- 1 Select the location (next page) where to insert the blank page on the preview screen of the archived job.
- 2 Click [Insert blank page].



The blank page is added in front of the selected page.



Deleting Pages [Delete]

- 1 Select the page to delete on the pre-view screen of the archived job.
- 2 Click [Delete].



The selected page is deleted.




Merging Multiple Archived Jobs

Multiple archives stored in the print controller can be selected and merged.

1 Selects the jobs to merge from the list of archived jobs.

Click the arbitrary jobs and select while holding down the **[Ctrl]** key of the computer. (With Macintosh computers, holding down the **[Alt]** key.) You can also select them by specifying the range of jobs while holding down the **[Shift]** key.



Important!:

- Archived jobs are merged in the order of selection.

Note:

- To cancel the selection, click the jobs you want to cancel while holding down the **[Ctrl]** key. (With Macintosh computers, holding down the **[Alt]** key.)

2 Move the mouse pointer over the [Job] menu button and then click [Merge] in the displayed submenu.

3 Enter the new job name, and click the [Ok] button.

After the job is processed, it is added to the list of archived jobs.


Merging Pages from Multiple Archived Jobs

- 1 Select the job to edit from the list of archived jobs, and display the preview screen.**


For details, see “Editing Archived Jobs” p.37.

- 2 In the same way, display the preview screen of the archived jobs to merge.**

- 3 Select the page to copy, then drag and drop the page at the merging location.**



The selected page is added to the merging location (before the specified page).



- 4 Save the merged archived data.**

- 1) Click the [Save changes] button on the preview screen.**
- 2) Enter the new job name, and click the [OK] button.**
After the job is processed, it is added to the list of archived jobs.

Note:

- To not save the merged archived data, click the [Close] button on the preview screen, and click the [Yes] button in the confirmation dialog box.

Saving Archived Jobs to the Computer


Archived jobs can be saved on the computer in two ways: downloading and exporting.
If downloaded, the file is saved as an image file (such as JPEG) or as a PDF file.
If exported, the file is saved in a format (.shae) that the print controller uses to read data.

When downloading

- 1 Click the **[Archive jobs]** button from the **Job / Queue** selection button (on the left side of the screen), and select the job you want to download from the list of archived jobs.

For details, see steps 1 and 2 in “Printing Jobs” p.15.

- 2 Click **[Feedback...]** in the **Job preview**.



The feedback setting screen is displayed.



- 3 Specify the data format and other settings for the download.



- **[From page] [To page]:** Specify the page to download from the archived data.
- **[Pack to zip file]:** When placing a checkmark, a zip-compressed job (The extension is .zip) is saved. This cannot be set for “TIFF” format.
- **[Resolution]**
[Screen]: Downloads the image with the resolution for screen display (75dpi).
[Full]: Downloads the image with the resolution for printing. This image can be used for checking before actual printing.
- **[File format]:** Select the file format to download (TIFF, PDF, PNG, or JPEG).
- **[Compression]:** Select the compression level (Lowest, Low, Medium, High, or Highest). This cannot be set for “TIFF” format.

Note:

- Image data can be also downloaded to the computer by moving the mouse pointer over the **[Job]** menu button and then clicking **[Feedback...]** in the displayed submenu.
- When printing data downloaded in the **[Full]** setting, be sure to print to a ComColor series (9150 / 9110 / 7150 / 7110 / 3150 / 3110) printer.


- 4 Click the [Download...] button.
- 5 Click the [Save] button.
- 6 Specify the destination folder and file name, and click the [Save] button.

The data is saved in the specified folder.

When exporting

- 1 Display the feedback setting screen.
For details, see steps 1 and 2 in “When downloading” p.43.


- 2 Click [Export job].



Note:

- The archived data can be also downloaded by moving the mouse pointer over the [Job] menu button and then clicking [Export job] in the displayed submenu.

- 3 Click the [Save] button.



- 4 Specify the destination folder and file name, and click the [Save] button.

The data is saved in the specified folder.

Note:

- The extension of the archived data is “.shae”.
- The archived data exported to the computer can be imported to the print controller. For details, see “Importing an Archived Job from the Computer” p.45.


Importing an Archived Job from the Computer


Archived jobs saved in the computer (the extension is .shae) can be imported to the print controller.


Note:

- Archived jobs (extension is .shae) are saved by exporting archived jobs or using the backup function of archived jobs. (p.44, p.67)

- Click the **[Archive jobs]** button from the **Job / Queue** selection button (on the left side of the screen).



- Click  of the **Job / Queue** information display (on the right side of the screen).



The Import archive job screen is displayed.



- Click the **[Browse]** button, and select the archived job.

After specifying the archived job on the file selection screen, click the **[Open]** button.

- Click the **[Import job]** button.

The archived job is imported and added to the list of archived jobs.

Checking Printer Status


The status screen of the printer can be displayed by moving the mouse pointer over the **[Printer]** menu button and then clicking **[Printer details...]** in the displayed submenu. After the checking is completed, click the **[Close]** button.

Note:

- You can also click the RISO Console screen status area to confirm printer status (the RISO Console screen for the printer is displayed). For details on the RISO Console screen for the printer, refer to the ComColor series (9150 / 9110 / 7150 / 7110 / 3150 / 3110) printer's instruction manual.


General

Clicking **[General]** displays the information on the printer and printer status.



Paper trays

Clicking **[Paper trays]** displays the paper set in the paper tray, paper quantity, and availability for auto tray selection.




Output trays

Clicking **[Output trays]** displays the status of the output tray.



Installable options

Clicking **[Installable options]** displays information on the printer and the configuration of optional devices connected to the printer.




Note:

- Setting items may vary depending on whether or not optional devices necessary for configuring settings are connected, as well as the settings of the printer itself.

Consumables


Clicking [**Consumables**] displays the remaining amount of ink in the printer.



Selecting Languages

Selects the language for messages displayed on the RISO Console screen.

Move the mouse pointer over [Language] menu button, and select the language you want to use from the list.



Note:

- The languages displayed on the RISO Console are memorised in the cookie of the web browser. Therefore, the language displayed when the RISO Console was last used will be enabled the next time the console is started up.



Administrator Settings

This section describes the administrator settings of the RISO Console (the available functions for administrator).

Administrator

The administrator is a user that has the authority to change the settings of the print controller, add queues, and register general users, etc. by logging in as an administrator.

Note:

- For user authority (guest user / general user / administrator), see “Logging in to the Print Controller” [p.9](#).

How to Log In

For login procedures for the print controller, see “Logging in to the Print Controller (General user / Administrator)” [p.9](#).

Important!:

- In the default settings, the login ID for the administrator is set to “Admin” and the password is set to “0000”. Be sure to set a password after the logging in as the administrator. [p.58](#)

Available functions for administrator

After logging in as the administrator, in addition to the available functions for general users, the following operations are enabled.

- Changing the detailed setting of the print controller [p.51](#)
Configuring the network settings, user management, job management, date / time, HDD backup of data settings, etc.
- Setting how job processing is distributed over the network by the print controller [p.62](#)
- Operation of queues (Create, Edit, Delete, Stop / Resume) [p.90](#)
- Viewing and saving the accounting (history) data [p.88](#)
- Viewing and saving system event information [p.87](#)
- Changing the settings of*1, copying, moving and viewing*2 jobs owned by other users. [p.21](#), [p.22](#), [p.24](#)
- Rebooting / Shutting down the print controller [p.96](#)


*1 The job's security code setting cannot be changed.

*2 Jobs for which a security code has been set cannot be viewed.

Detailed Settings of the Print Controller

This section describes how to make network settings, time settings, change the login password to the administrator setting, etc for the print controller.

The detailed setting screen for the print controller can be displayed by moving the mouse pointer over the **[RIP]** menu button and then clicking **[RIP details...]** in the displayed submenu.



Clicking the icons at the top of the screen switches to the corresponding setting screen.


[Ok]: Click to save setting changes and end editing.

[Apply]: Click to save setting changes and continue editing.

[Cancel]: Click to cancel setting changes and end editing.

General

Displays the status and detailed information of the print controller.



Displayed information

1) RIP status

Displays the current status of the print controller.

2) Pages to print

Displays the total number of pages of jobs in the Normal queue (the number of pages of each job x the number of copies).

Note:

- Jobs in the Hold queue and jobs in stopped processing status are not included.

3) Job count

Displays the number of jobs in the Normal queue.

Note:

- Jobs in the Hold queue and jobs in stopped processing status are not included.

4) Comment

The comment concerning the print controller can be entered.

5) Detailed information

Displays an outline and network settings of the print controller. You can also check error messages and the finished (progress) status.

6) Status report



The detailed information of the print controller can be downloaded in text format (file extension .txt).

Actions

- Inputting comments
When you click the input area, a comment can be entered. Up to 511 characters can be entered. Comments should be written in one line.
- Downloading status report
When you click the **[Download]** button and specify the destination folder and file name, the detailed information of the print controller is saved in text format (file extension .txt).

Communication settings

The current network settings of the print controller are displayed under **[Current settings]**. To change a setting, enter the new setting under **[After restart]**. The changed settings are applied after the print controller is restarted.



Settings

1) RIP name

Enter the name of the print controller. Enter up to 15 characters, using alphanumeric characters and hyphens. The entered name is displayed as the printer name on the network.

Note:

- Enter an alphabetic character as the first digit in the name.
- Enter an alphabetic character or numeric character as the last digit in the name.

2) Domain

Enter the domain name of the network to which the printer is connected.

3) EtherTalk zone

When using the printer via AppleTalk, enter the AppleTalk zone name of the network to which the print controller is connected.

“ * ” indicates that the print controller is enabled for all zones.

4) NetBIOS workgroup

When the communications are conducted using NetBIOS, enter the NetBIOS workgroup name.

5) IPv4

This setting is for establishing a network connection via Internet Protocol version 4.

- Use DHCP
Place a checkmark in this box if you will use a DHCP server for acquiring an IP address.
- IP address
Enter the IP address to assign to the print controller.

Important!:

- Enter an IP address that is different from the one you entered for 12) **[Engine IP Configuration]**.
- Subnet mask
Enter the subnet mask of the network to which the print controller is connected.
- IP gateway
Enter the gateway address of the network to which the print controller is connected.

6) IPv6

This setting is for establishing a network connection via Internet Protocol version 6.

- Entering an IP address
IPv6 can be set to one of the following settings via the pull-down menu.
[Manual]: Enter the IP address or IP gateway and IP prefix values. (Default setting: Manual)
When **[Stateless address]** is selected: The IP address or IP gateway and IP prefix are greyed out.
When **[Stateful address]** is selected: The IP address or IP gateway and IP prefix are greyed out.

7) Name server

If you are using a DNS server to connect to the network, enter the IP address of the DNS server.

Note:

- When **[Use DHCP]** is set, the DHCP server settings specified above are applied for the DNS server.

8) Mail server

To use e-mail notification, enter the IP address of the mail server.

9) Sender address

To use e-mail notification, enter the e-mail address of the source.

10) Ethernet address

Displays the Ethernet address of the print controller.

11) Enforce https

Place a checkmark to connect the print controller by https (encrypted communication) when using the RISO Console. When a checkmark is placed, the screen automatically jumps to https:// (IP address of the controller) even if you connect to the print controller by http:// (IP address of the controller).

When displaying the screen, a dialog box concerning security warning (authentication verification) is displayed. Click the **[Yes]** button to continue.


12) Engine IP Configuration

The printer and the controller are directly connected using the dedicated LAN cable, therefore your network environment is not affected. However, select a configuration of IP addresses without possible conflict as a precaution.

| Selection | Controller | Printer |
|-----------------|-----------------|-----------------|
| Configuration 1 | 10.255.255.251 | 10.255.255.252 |
| Configuration 2 | 172.16.255.251 | 172.16.255.252 |
| Configuration 3 | 192.168.255.251 | 192.168.255.252 |

IPSec Settings


By using encryption technology for the network environment used in your user environment, you can prevent data leakage and tampering. Set this in order to strengthen security functions. Setting items for **[Security Policies]** vary depending on the network environment that you use.



Settings

- 1) IPSec enabled**
Enables or disables IPSec settings.
- 2) Reject unregistered packets**
Sets whether unregistered packets are rejected or received.
- 3) Security policy registration**
You can register up to 10 security policies.
- 4) Add**
Adds a new security policy.
- 5) Edit**
Configures detailed settings for the selected security policy.
- 6) Delete**
Deletes the selected security policy.
- 7) ▲▼ (sort)**
Changes priorities for security policies.

Set details for security policies



Settings (Basic / IKE / Communication)

- 1) **Security Policy Name**
Enter the security policy name using only alphanumeric characters within 32 characters.
- 2) **Pre-shared Key / Confirm Pre-shared Key**
Enter the pre-shared key using only alphanumeric characters from 0 to 32 characters. Configure **[Confirm Pre-shared Key]** with the same settings.
- 3) **Scope (IPv4)**
Sets whether to restrict application of the IPv4 security policy.
When restricting the application of the IPv4 security policy, set the IP address and the subnet mask.
- 4) **Scope (IPv6)**
Sets whether to restrict application of the IPv6 security policy.
When restricting the application of the IPv6 security policy, set the IP address and the IP prefix.
Prefix: 0 to 64 to 128
(Default: 64)
- 5) **IKE Mode**
Sets the IKE communication mode to Main or Aggressive.
- 6) **Encryption Algorithm***
Selects the encryption algorithm to use.
- 7) **Hash Algorithm***
Selects the Hash Algorithm to use.
- 8) **DH Group***
Selects the DH Group to use.
- 9) **Lifetime**
Sets the communication lifetime from 1800 to 86400 seconds.
- 10) **Authentication Algorithm**
Sets the authentication algorithm to AH, EPS or AH+EPS.
- 11) **Encryption Algorithm**
Selects the encryption algorithm to use.
- 12) **PFS**
Sets Perfect Forward Secrecy.
- 13) **PFS Group**
Selects the PFS group to use.

* There is an equivalent setting for Communication.

Setting security policies (registering new policies and changing settings)

To add a new security policy, press **[Add]**. To change a registered security policy, select the **[Security Policies]** item that you want to change, and press **[Edit]**. The **[Security Policy Settings]** screen is displayed.

Note:

- Setting items vary depending on the network environment that you use. Set the necessary items.
- If the security policy name has already been registered to another security policy, a confirmation message is displayed. Re-enter the security policy name.
- An error message is displayed when **[Pre-shared Key]** and **[Confirm Pre-shared Key]** do not match. Re-enter the same pre-shared key.


- 1) Configure basic settings
- 2) Configure IKE settings
- 3) Configure communication settings

Note:

- If **[Authentication Algorithm]** is set to **[AH]**, **[Encryption Algorithm]** does not need to be set. If **[PFS]** is set to **[OFF]**, **[DH Group]** does not need to be set.

User management

You can configure the settings for managing the users of the print controller.



Settings

- 1) **Edit existing user**
Registered user names are displayed in the list box. Sets the deleting user, changing language, changing password and enabling/disabling FTP access.
- 2) **Create new user**
Registers the user by entering the user name and the password.
- 3) **Others can see jobs**
Enables / disables access to jobs of different owner.
- 4) **Allow anonymous FTP**
Enables / disables FTP access by anonymous users.
- 5) **Enforce login**
Sets whether the login is enforced or not when using the RISO Console.
Important!:
 - If the printer mode is set to **[Required]** for the printer's administrator setting (login setting), check this item.
- 6) **Default language**
Sets the language to be used when an unregistered user uses the notification function.
- 7) **Auto logout time**
Sets the time for automatic logout when a logged in user performs no operations for an extended period of time.

Registering New Users

- 1) Enter the new user name in the **[User name]** input area.
As the user name, enter the name used when logging into the network. (Refer to the names displayed as owner names in the job list)
- 2) Enter the password in the **[Password]** input area.
Enter a password in 0 to 31 characters using alphanumeric characters and symbols (!"#\$%&'()*+,-./:;<=>?@[^_`{|}~).
- 3) Re-enter the password in the **[Retype password]** input area.
- 4) Click the **[Create]** button.
The user is registered, and the user name is added to the list of registered user names on the left side of the screen.

Note:

- For optimum print controller performance, we recommend no more than 300 users be registered.

Deleting Registered Users

- 1) Select the user name to delete from the list of the names of registered users.
- 2) Click the **[Delete user]** button.
The user is deleted.

Changing Passwords

- 1) Select the user name to which the password will be changed from the list of the names of registered users.
- 2) Enter the new password in the **[New password]** input area.
Enter a password in 0 to 31 characters using alphanumeric characters and symbols (!"#\$\$%&'()*+,-./:;<=>?@[^_`{|}~).
- 3) Re-enter the new password in **[Retype new password]** the input area.
- 4) Click the **[Change password]** button.
The password is changed.

Note:

- When the entry for **[New password]** does not correspond to that for **[Retype new password]**, an error message is displayed. Enter the same password again.

Changing the Language of Notifications

- 1) Select the user name from the list of the names of registered users.
- 2) Select a language from the **[Notification language]** combo box.
- 3) Click the **[Apply]** button.
Set the language to be used for notification functions such as e-mail notifications to selected users.

Enabling / Disabling FTP Access


- 1) Select a user name from the registered users list.
- 2) Enable / disable FTP access.
When enabling FTP access, place a checkmark in **[Allow FTP]**.
- 3) Click the **[Apply]** button.

Changing General User Settings

- When a checkmark is placed in **[Others can see jobs]**, access to jobs of different owners is enabled.
- When a checkmark is placed in **[Allow anonymous FTP]**, FTP access by anonymous user is enabled.
- When a checkmark is placed in **[Enforce login]**, entry by login ID and password is enforced in using the RISO Console.
When **[Enforce login]** is set, only the login information input area and some operations can be used. (The operations that cannot be used are greyed out.)
- From the **[Default language]** combo box, select the language to be used when a notification function is used by an unregistered user.
- If **[Auto logout time]** is set, a logged in user will be logged out if the user performs no operations for the set amount of time.
If set to **[0]**, the auto logout function is deactivated.

Job settings

This screen is for making settings concerning job processing by the print controller.



Settings

1) ASCII printing

Enables / disables printing of ASCII text jobs.

2) Default page size

Sets the page size applied to the jobs for which a page size has not been set.

3) Generate Job Info Events

Sets whether or not to generate the detailed events in the Details column in **[Logging]** of **[Job details]**.

4) Job name from file name

Sets the display of the job's file name in the job list.

5) Job auto delete

Sets the deletion method and timing for finished jobs in the **[Finished job]** list.

ASCII File Print Settings **[ASCII printing]**

When placing a checkmark in **[ASCII printing]**, ASCII text jobs can be printed. When a job of unknown file format has been received, the job is printed in ASCII text.

Note:

- When **[ASCII printing]** is enabled, all jobs except for PostScript, PCL, PDF, PPML (optional) and TIFF files are printed in ASCII text.

Setting Default Page Size **[Default page size]**

From the **[Default page size]** combo box, select the page size applied to jobs for which a page size has not been set.

Note:

- Jobs for which a page size has not been set are, for example, sample pages stored in the print controller and print jobs created by printer drivers except the printer driver of this print controller.

Generate the detailed job information events **[Generate Job Info Events]**

When placing a checkmark, the detailed job information events can be generated in the Details column in **[Logging]** of **[Job details]**.

Note:

- When placing a checkmark, the processing speed will slowdown.

Displaying the file name in the job list [Job name from file name]

When placing a checkmark, the job's file name is displayed in the job list's "Name".

Setting the deletion method of finished jobs [Job auto delete]

Set whether to delete the finished jobs stored in the **[Finished job]** list automatically or manually.

- 1) Select **[Automatically]** or **[Manual]** in **[How]** of **[Job auto delete]**.
When **[Automatically]** is selected, proceed to step 2. When **[Manual]** is selected, other settings are not required.
- 2) Select the unit of deletion timing in **[When]**.
[By hours]: When the set time elapses, jobs are automatically deleted.
[By days]: When the set number of days elapses, jobs are automatically deleted.
[By amount]: When the number of stored jobs exceeds the set number, jobs are automatically deleted in chronological order with the oldest job deleted first.
- 3) Enter the reference number in the **[Value]** input area.
The timing of automatic deletion is decided in conjunction with the unit selected in step 2.


RIPs in network

When several print controllers of the same model are connected to the network, each job can be delegated to a different print controller for processing.

Specify the print controllers that can be used for job delegation.

Note:

- Only the IS1000C / IS950C can be specified as the print controller for load balancing. Load balancing with other models and non-RISO print controllers is not possible.
- The system for load balancing can consist of one master controller and one to four client controllers. The load balancing settings are made by the master controller. No settings are required on the client controller side.



Actions

- | | |
|--|---|
| <p>1) Refresh RIP list from network Searches for IS1000C / IS950C connected to the network.</p> <p>2) Direct input and addition of Name / IP address Adds the name and IP address of the print controller to the list by direct input.</p> | <p>3) Deletion from the controller list Deletes the print controllers from the list.</p> <p>4) Load balancing Sets whether or not the print controller in the list is used for distributed processing (for load balancing).</p> |
|--|---|

Searching for Print Controllers on the network [Refresh RIP list from network]

When clicking the [Refresh RIP list from network] button, the IS1000C / IS950C connected to the network is searched and the list with the latest information is updated.

Direct input and addition of Name / IP address [Name] [IP address] [Add]

Adds the name and IP address of the print controller to the list by direct input.

[Name]: Enter the RIP name. If DNS is not configured, enter the IP address.

[IP address]: Enter the IP address of the print controller.

[Add]: The name and IP address are added to the list.

Job delegation setting [Load balancing]

When placing a checkmark in the checkbox on the right side of Name / IP address of the print controller, the print controller can be used for load balancing (load distribution processing).


Deleting from the controller list [Delete]

When clicking the **[Delete]** button on the right side of Name / IP address of the print controller, the print controller is deleted from the list.

Click **[Ok]** or **[Apply]** to confirm the settings.

Time settings

Synchronises the print controllers' time settings with the computer's time settings.



Displayed information

1) PC time

Displays time settings of the computer.

2) RIP time

Displays time settings of the print controller.

Actions

• [Synchronize]


When clicking the button, the print controller's time settings will be synchronised with the computer's time settings.

Note:

- Time zone settings are also synchronized with the settings of the computer.

Monitor settings

This screen is for screen saver-related settings.



Settings

1) Enable monitor

Sets whether or not you use the monitor. When you do not use the monitor, remove the checkmark.

2) Auto logout time

Sets the time for automatic logout when a logged in user performs no operations for an extended period of time.

3) Enable screensaver

Sets whether or not to use the screensaver.

4) Screensaver

Select the screensaver to use.

5) Screensaver timeout

Sets the time (in minutes) before the screensaver starts when the monitor is unused for an extended period of time.

Enabling the monitor [Enable monitor]

When the monitor is connected, place a checkmark in the **[Enable monitor]** checkbox. When the monitor is not connected, remove the checkmark.

Setting the automatic logout time [Auto logout time]

Sets the time for automatic logout when a logged in user performs no operations for an extended period. The time can be entered in a range from 0 to 99 minutes (the initial value is 2 minutes).

Note:

- When the automatic logout time is set to 0 minutes, automatic logout will not be performed. To logout in this case, click the **[Log out]** button.


Setting up the Screensaver

Sets whether or not to use the screensaver when the monitor is unused for an extended period of time.

- Enable screensaver**
Place a checkmark in **[Enable screensaver]** when using the screensaver.
- Screensaver**
The screensaver can be selected from the list of usable screensavers.
- Screensaver timeout**
Sets the time at which the screensaver starts.
The time can be entered in a range from 1 to 999 minutes (the initial value is 5 minutes).

Backup

This screen is for exporting various settings of the print controller to the computer and importing settings from the computer.



Settings

1) Backup queues

Settings of the queues can be exported to or imported from the computer.

2) Backup users

User information set in **[User management]** can be exported to or imported from the computer.

3) Backup archive jobs

All archived jobs saved in the print controller can be exported to or imported from the computer.

4) Backup hold jobs

All held jobs saved in the print controller can be exported to or imported from the computer.

Note:

- When importing data, data for which **[Clear before import]** is marked with a checkmark will be deleted then imported.

Exporting queue settings to the computer [Export queues]

Click the **[Export queues]** button, and enter the destination folder and file name, and then execute the save. All the queue settings currently registered in the print controller are saved. The file is saved in text format (file extension .txt).

Importing queue settings from the computer [Import queues]

Click the **[Browse]** button, and specify the queue setting file to import (file extension .txt). Click the **[Import queues]** button, and execute the import to the print controller.

Note:

- The imported queue is added to the existing queues in the print controller.
- When there is the same queue name as the imported queue in the print controller, the existing queue will be overwritten with the information of the imported queue.

Exporting user information to the computer [Export users]

For backup purposes:

Click the **[Export users]** button, set the file format to XML, enter the destination folder and file name, and then execute the save.

All user information (except for the administrator) currently registered in the print controller is saved.

The file is saved in text format (file extension .txt).

For batch registration purposes:

Click the **[Export users]** button, set the file format to CSV, enter the destination folder and file name, and then execute the save.

All user information (except for the administrator) currently registered in the print controller is saved.

The file is saved in CSV format (file extension .csv).

Note:

- For XML, passwords are encrypted and saved.

Importing user information from the computer [Import users]

For backup purposes:

Click the **[Browse]** button, and specify the user information file to import (file extension .txt).

Finally, click the **[Import users]** button and execute the import.

For batch registration purposes:

Click the **[Browse]** button, and specify the user information file to import (file extension .csv).

Finally, click the **[Import users]** button and execute the import.

Note:

- If the printer mode is set to **[Required]** for the printer's administrator setting (login setting), the following procedure is recommended for importing registered user information.

1) Using the printer's administrator setting (user setting), use **[Export as CSV]** to export the data.

2) Use the print controller **[Import users]** function to import the saved CSV file.

The data entered in the **[PC login name]** column of the CSV file is registered in the print controller as user information.

- When the settings of the same user exists in the print controller, the existing settings will be overwritten with the settings imported.


Exporting multiple archived jobs to the computer [Export archive jobs]

Click the **[Export archive jobs]** button, enter the destination folder and file name, and then execute the save.

All archived jobs currently saved in the print controller are saved in one file.

The file is saved with a .shae extension.

Note:

- Archived jobs can be also individually saved.
"When exporting"  p.44
- Files can be saved up to 2 GB in size.

Importing multiple archived jobs from the computer [Import archive jobs]

Click the **[Browse]** button, and specify the archived jobs file to import (file extension .shae). Click the **[Import archive jobs]** button to import to the print controller.

Note:

- The imported archived jobs are added to the list of archived jobs.

Exporting Held Jobs to the Computer [Export hold jobs]

Click the **[Export hold jobs]** button, and enter the destination folder and file name, and then execute the save. All held jobs currently saved in the print controller are saved in one file. The file is saved with a .shhe extension.

Note:

- Files can be saved up to 2 GB in size.

Importing held jobs from the computer [Import hold jobs]

Click the **[Browse]** button, and specify the held jobs file to import (file extension .shhe). Click the **[Import hold jobs]** button, and execute the import to the print controller.


Note:

- The imported held jobs are added to the list of held jobs.

SNMPv3

The risk of data eavesdropping and tampering can be lowered by applying authentication and encryption to “SNMP packets” used in network communications.

Specify the settings for SNMPv3 by using a CSV file for each MIB type.



Settings

1) Private MIB

2) MIB2(RFC1213)

3) Host Resource MIB(RFC1514)

4) Printer MIB(RFC1759)

Individual encryption settings for 1) to 4) can be configured by using CSV files.

[Upload configuration...]: Imports an SNMPv3 setting file from a computer to this product’s hard disk drive.

[Download configuration...]: Exports an SNMPv3 setting file from this product’s hard disk drive to a computer.

5) Job Monitoring MIB

You can turn encryption settings on or off all at once via Job Monitoring MIB.

Setting SNMPv3 by using a CSV file for each MIB type

- 1) Click **[Download configuration...]** and download the CSV file.
- 2) Enter the necessary items in the SNMPv3 file, and save it to your computer.
- 3) Upload the SNMPv3 CSV file saved in step 2 to this product's hard disk drive.
Click **[Upload configuration...]**.
- 4) Set **[Job Monitoring MIB]** encryption as necessary.


Note:

- CSV file definition
 - Line 1: Title line
 - Line 2: MIB name
 - Line 3: Version information
 - Line 4 and below: Index, encryption settings, administrator privileges (set access privileges for users with administrator privileges), user privileges (set access privileges for regular users)
- CSV file example

| | | | | |
|---------|-------------|-------------|------------------------------|--------------------|
| Line 1: | OID, | Encryption, | Administrator authorization, | User authorization |
| Line 2: | Printer MIB | | | |
| Line 3: | 1 | | | |
| Line 4: | 1.1.2.1, | ON, | RW, | R |
| Line 5: | 1.1.2.2, | OFF, | RW, | N/A |

HDD backup

All of the data saved to the print controller can be cumulatively backed up to an external hard disk drive. Additionally, all settings, such as backed up form selections and queue selections, can be cumulatively restored.



Displayed items

- 1) **Last backup/restore results**
Information from the last backup and/or restore is displayed. If no backups or restores have been performed yet, this area will be blank.
- 2) **[Backup] tab**
Cumulatively back up the settings data saved on the print controller to an external hard disk drive.
- 3) **[Restore] tab**
Restore the backup data saved to an external hard disk drive to the print controller.
- 4) **[Delete] tab**
Delete the backup data saved to an external hard disk drive.

5) Backup data list

Displays a list of all the times and dates, comments, data volumes, and backup results for the HDD backups which have been performed.

Cumulatively backing up settings data [Backup]

Important!:

- If the print controller's internal hard disk drive is damaged, it is necessary to install a new hard disk drive with specialty firmware. Contact your dealer (or authorized service representative).
- During backup, print controller operations are stopped. The RISO console is also inaccessible.
- During backup, only functions on the printer which do not use the print controller can be used.
- After backup has finished, information, such as whether or not the operation finished normally, is printed automatically. Set the printer so that it can be used.
- If an external hard disk drive is not connected to the print controller or if the external hard disk drive cannot be accessed, an error will occur. If an error occurs, the ERROR lamp on the print controller will light up.
- Use the external hard disk drive exclusively for the backup for the print controller. Do not use it with other devices.

Note:

- We recommend an external hard disk drive with the following specifications.
 - USB connection (Network connections are not possible)
 - 500GB or more of free space
 - Self-powered

1) Connect the external hard disk drive to the print controller USB connector.

2) Check that the contents of the **[Backup]** tab are displayed.

If they are not displayed, click the **[Backup]** tab.

The volume of the settings data to be backed up and the amount of free space on the external hard disk drive are displayed.

3) Set each of the items.

Important!:

- If there is not enough free space on the external hard disk drive, a warning message will be displayed before backup begins. Check the volume of the data to be backed up and the amount of free space on the external hard disk drive.


[Comment]: Comments between 1 and 32 characters in length can be entered in order to identify backed up data. We recommend easy-to-understand names such as "2014 maintenance".

(Default: The date and time when the **[Backup]** screen is displayed)


[Action after backup]: Select the behavior for the print controller once backup has finished.

(Default: Shutdown)

- **[Reboot]:** Reboots the print controller. After automatically printing information, such as whether or not backup finished normally, normal operation will begin.
- **[Shutdown]:** Shuts down the print controller. The next time the print controller is powered on, information, such as whether or not backup finished normally, will be automatically printed.



- 4) Click the **[Perform HDD backup]** button.
A confirmation screen is displayed.
- 5) Click the **[Yes]** button.



Backup begins and the print controller DATA lamp blinks.
Once backup has finished, the print controller will perform the operation set for **[Action after backup]**.

Note:

- If an error occurs, the print controller ERROR lamp lights up.
- Files made when an error occurs are displayed in the Backup data list with **[Error]** under **[Result]**. Delete these files since they cannot be restored.
- The blinking speed of the DATA lamp changes with the progress of the backup. As the backup progresses, the speed increases.

Cumulatively restore settings data **[Restore]**

Important!:


- During restore, the print controller operations are stopped. The RISO console is also inaccessible.
- During restore, only functions on the printer which do not use the print controller can be used.
- After restore has finished, information, such as whether or not the operation finished normally, is printed automatically. Set the printer so that it can be used.
- If an external hard disk drive is not connected to the print controller or if the external hard disk drive cannot be accessed, an error will occur. If an error occurs, the ERROR lamp on the print controller will light up.
- Set the printer so that it does not go into power saving mode during restore.
For more information on the power saving function, refer to the “Printer’s User’s manual”.

Administrator Settings


- 1) Connect the external hard disk drive to the print controller USB connector.
- 2) Click the **[Restore]** tab.
- 3) In the backup data list, click the backup data to be restored.

Note:

- Only one backup data file can be selected.
- Only backup data which has **[OK]** under **[Result]** can be selected.




- 4) Select the behavior for the print controller once restore has finished with **[Action after backup]**. (Default: Reboot)
 - **[Reboot]**: Reboots the print controller. After automatically printing information, such as whether or not restore finished normally, normal operation will begin.
 - **[Shutdown]**: Shuts down the print controller. The next time the print controller is powered on, information, such as whether or not restore finished normally, will be automatically printed.



- 5) Click the **[Restore HDD backup]**.
A confirmation screen is displayed.

6) Click the **[Yes]** button.



Restore begins and the print controller DATA lamp blinks.

Once restore has finished, the print controller will perform the operation set for **[Action after backup]**.

Important!:

- If trouble occurs and the restore fails*, the data on the print controller's internal hard disk drive is deleted.
 - * If the external hard disk drive is disconnected or the power supply is cut due to lightning, a blackout, an accident, etc., the restore may fail.
- If the print controller restarts after a restore fails, perform the restore again.
 - If the print controller does not restart after a restore fails, contact your dealer (or authorized service representative).

Note:


- The blinking speed of the DATA lamp changes with the progress of the restore. As the restore progresses, the speed increases.

Delete backup data [Delete]

- 1) Connect the external hard disk drive to the print controller USB connector.
- 2) Click the **[Delete]** tab.
- 3) In the backup data list, click the backup data to be deleted.

Note:

- Only one backup data file can be selected.




Click the **[Delete HDD backup]** button.
The selected backup data is deleted.

Customization Settings

Frequently used form data, user defined paper sizes, barcode areas, and PCL tray settings can be registered in the print controller in advance.

The customization setting screen can be displayed by moving the mouse pointer over the **[RIP]** menu button and then clicking **[Custom preferences...]** in the displayed submenu.



Clicking the icons at the top of the screen switches to the corresponding setting screen.

[Ok]: Click to save setting changes and end editing.

[Apply]: Click to save setting changes and continue editing.

[Cancel]: Click to cancel setting changes and end editing.

Custom forms

Register the frequently used form data.

The custom forms registered here are displayed by the combo boxes - **[Form 1 (all pages or front)]**, **[Form 2 (back)]**, **[Prepend job]**, and **[Append]** - on the **[Forms]** screen of the **[Job details]** menu or printer driver. “[Forms] Screen” [p.31](#)

Settings

- Custom form 1 to 10
Archived jobs saved in the print controller are allocated to custom forms.

Setting up custom forms

In the combo box of the custom form you want to set, select the name of the archived job to allocate.

Note:


- Data to be used as a custom form must first be archived. [p.14](#)

Custom paper sizes

Registers irregular paper sizes.

The paper sizes registered here are displayed in the **[Output size]** combo box in the **[Layout]** screen of the **[Job details]** menu or printer driver.

“[Layout] Screen” p.27



Settings

- Custom 1 to 99
Registers the **[Width in mm]** or **[Width in inch]** and **[Height in mm]** or **[Height in inch]** to the paper names.

Setting custom paper sizes (user defined sizes)

Enter a numeric value (mm or inch) in the **[Width in mm]** or **[Width in inch]** box and the **[Height in mm]** or **[Height in inch]** box on the right side of the paper name.

Note:

- Set the custom paper sizes within the range of paper sizes that can be used by the printer. For details, see the “Printer’s User’s manual”.
- Available paper sizes vary depending on the model of the optional finisher connected. For details, see the “Printer’s User’s manual”.

PCL tray mapping

Set the allocation of trays to be used when processing PCL jobs.

| Standard tray | Tray numbers in PCL job |
|---------------|-------------------------|
| Standard tray | 4 |
| Tray 1 | 1 |
| Tray 2 | 2 |
| Tray 3 | 3 |

Actions

Assign the tray number specified in the PCL job to a tray of the printer.

Setting tray allocation for PCL jobs

Enter the tray numbers in the PCL job as the printer trays: **[Standard tray]**, **[Tray 1]**, **[Tray 2]**, and **[Tray 3]**.


Note:

- When entering multiple tray numbers in the **[Tray numbers in PCL job]** box, separate the numbers by commas (,).
- When a High Capacity Feeder is connected, **[High capacity feeder]** is displayed.

Barcode area

Operations such as registration or deletion of barcode area definition files (CSV file) and images of the registered barcode area can be checked here.

The barcode print area can be set by installing the supplied ComColor (9150 / 9110 / 7150 / 7110 / 3150 / 3110) printer driver "Barcode Area Definition". For details on how to use the application, refer to "Using the Barcode Area Definition Application" in the printer's "Basic Guide".



Information displayed / Settings

1) Barcode Area Definition File

Displays a list of the registered barcode area definition files (CSV files). The file names displayed here will appear on the **[Job Details]** screen or in the pull-down menu of **[Barcode Area Definition]** on the **[Image]** screen of the printer driver. For details, see "**[Image]** screen" p.30.

2) Rename

Changes the barcode area definition file (CSV file) name.

3) Delete

Deletes a barcode area definition file (CSV file).

4) Download

Downloads a barcode area definition file (CSV file) to the computer.

5) Upload

Uploads a barcode area definition file (CSV file) from the computer.

6) Preview

Displays the barcode definition position image of the file selected from the list of the barcode area definition files.

Deleting the barcode area definition file (CSV file) [Delete]

Select a file name that you want to delete from the list of the barcode area definition files and click **[Delete]**.

Downloading a barcode area definition file (CSV file) to the computer [Download]

Select a file name that you want to download to the computer from the list of the barcode area definition file and click **[Download]**. Input the destination folder and file name, and save the file.

Uploading a barcode area definition file (CSV file) from the computer [Upload]

Click **[Upload]** and specify the barcode area definition file (CSV file) that you want to upload to the controller. The uploaded area definition file appears in the **[Barcode Area Definition File]** list.


Creating a barcode area definition file

- 1) Set **[Destination]** to **[Create Print Data]** in the **[Workflow]** screen of the printer driver.
For details, refer to the separate manual “Printer Driver Guide” (p.70).
- 2) In the **[Finished jobs]** list in the console, specify the job you exported in step 1, and click **[Download...]**.
A PRN file is created in the specified location.
- 3) Start the barcode area definition application, and open the PRN file saved in step 2.
For details on steps for operation, refer to “Using the Barcode Area Definition Application” in the printer’s “Basic Guide”.
- 4) Specify the barcode areas.
- 5) Export the barcode area definition file in CSV format.
- 6) Register the barcode area definition file exported in step 5.

Color calibration

Color calibration information can be exported to or imported from the computer.

The **[Color calibration]** screen can be displayed by moving the mouse pointer over the **[RIP]** menu and then clicking **[Color calibration]** in the displayed submenu.



Exporting the color calibration information to the computer **[Export calibration]**


Click the **[Export calibration]** button, enter the destination folder and file name, and then execute the save. The file is saved in text format (file extension .txt).

Importing color calibration information from the computer **[Import calibration]**

Specify the color calibration information file to import (file extension .txt), and click the **[Import calibration]** button to import to the print controller.

Note:

- The existing color calibration information will be overwritten with the imported information.


When finished checking, click  to close the screen.

Profile management

Profiles used in color management settings can be added / deleted.

For color management settings, see “[Color] Screen” p.35.

The **[Profile management]** screen can be displayed by moving the mouse pointer over the **[RIP]** menu and then clicking **[Profile management]** in the displayed submenu.



Deleting profiles [Delete]


Select the name of the profile to delete from the profile list, and click the **[Delete]** button.

Note:

- The preinstalled profiles cannot be deleted.


Uploading profiles [Upload profile...]

1 Click the [Upload profile...] button.



2 Specify the profile to import. (The extension is .icc.)

3 Click the [Upload ICC profile] button.
The following screen is displayed.



4 Select the use of the profile using the radio buttons.

5 Click the [Import ICC profile] button.
The profile is imported to the print controller, and the profile name is added to the profile list.


6 When the operation is completed, click  to close the screen.

Font management

The list of fonts installed in the print controller is displayed.

Also additional fonts can be installed or deleted.

The **[Font management]** screen can be displayed by moving the mouse pointer over the **[RIP]** menu and then clicking **[Font management]** in the displayed submenu.



Downloading fonts [Download]

Click the **[Browse]** button, and select fonts to download.

Click the **[Download]** button, and execute the download to the print controller.

Note:

- The names of downloaded fonts are added to the list of installed fonts. After the installing is completed, click the **[Close]** button to close the screen.
- To download multiple fonts, select multiple font image files compressed in zip format, and click the **[Download]** button.

Deleting a font [Delete]

Select the font you want to delete from the list of installed fonts, and click the **[Delete]** button.


Note:

- Newly installed font names are displayed in black. Fonts displayed in grey are the fonts installed at the factory. These fonts cannot be deleted.

Reports

Information such as the print controller processing (event) information and information on the job processing are displayed. Also events settings can be set.

The report screen can be displayed by moving the mouse pointer over the **[RIP]** menu and then clicking **[Reports]** in the displayed submenu.



Clicking the icons at the top of the screen switches to the corresponding setting screen.

[Ok]: Click to save setting changes and end editing.

[Apply]: Click to save setting changes and continue editing.

[Cancel]: Click to cancel setting changes and end editing.

Log settings

This screen is for making settings for events that occur with the print controller.

Settings

1) Notification to E-mail address

Enter the e-mail address to notify event information of the print controller.

2) No duplicates within ... minutes

Sets not to notify the same event if it occurs within the set amount of time.

3) Event information notification method (The method can be set according to the type of event.)

- Info
- Consumables warning
- Warning
- Consumables error
- Error
- Fatal error
- Job info

4) System event auto delete

Sets the deletion method and timing for event information stored in the print controller.

5) Accounting log auto delete

Sets the deletion method and timing for accounting information stored in the print controller.

Setting the Destination of E-mail Notification [Notification to E-mail address]

In the [Notification to E-mail address] input area, enter the e-mail address to notify event information to. When e-mail is not used for notification, entry into the input area is not required.

Preventing duplicated notification of the same event [No duplicates within ... minutes]

Enter the number (minute) in the **[No duplicates within ... minutes]** input area. The same event that occurs within the set amount time is set to be not notified.

If the same event occurs repeatedly in a short period of time, such as the case that the cover of the printer is frequently opened and closed to clear paper jams, this setting prevents repeated recording of events of the same content and e-mail notification.

- The time can be entered in a range from 0 to 1440 minutes (the default value is 10 minutes).

Setting the Notification Method of Event Information

Set the notification method according to the type of event. Select the notification method in the combo box of each item.

- Type of event
 - [Info]**: Information concerning the boot of the print controller, and the start and end of processing
 - [Consumables warning]**: When there is little paper or ink remaining
 - [Warning]**: When there is little space on the hard disk
 - [Consumables error]**: When there is no paper or ink left
 - [Error]**: When there is no space left on the hard disk
 - [Fatal error]**: When a serious system failure has occurred
 - [Job info]**: Information concerning the processing of job
- Notification method
 - [Off]**: Does not record the event.
 - [Log]**: Records the event.
 - [Log and mail]**: Records the event and sends e-mail notification to the set destination e-mail address.
 - [Mail]**: Sends e-mail notification to the set destination e-mail address.

Setting the Deletion Method of Event Log [System event auto delete]

Set whether event information stored in the print controller is deleted automatically or manually.

When **[Automatically]** is selected, set the deletion timing.

- 1) Select **[Automatically]** or **[Manual]** in **[How]** of **[System event auto delete]**.
When **[Automatically]** is selected, proceed to step 2. When **[Manual]** is selected, other settings are not required.
- 2) Select the unit of deletion timing in **[When]**.
 - [By hours]**: When the set time elapses for event information, the event information is automatically deleted.
 - [By days]**: When the set number of days elapses for event information, the event information is automatically deleted.
 - [By amount]**: When the number of stored event information exceeds the set number, jobs are automatically deleted in chronological order with the oldest job deleted first.
- 3) Enter the reference number in the **[Value]** input area.
The timing of automatic deletion is decided in conjunction with the unit selected in step 2.

Setting the deletion method of accounting information [Accounting log auto delete]


Set whether accounting information stored in the print controller is deleted automatically or manually.

When **[Automatically]** is selected, set the deletion timing.

- 1) Select **[Automatically]** or **[Manual]** in **[How]** of **[Accounting log auto delete]**.
When **[Automatically]** is selected, proceed to step 2. When **[Manual]** is selected, other settings are not required.
- 2) Select the unit of deletion timing in **[When]**.
 - [By hours]**: When the set time elapses for accounting information, the accounting information is automatically deleted.
 - [By days]**: When the set number of days elapses for accounting information, the accounting information is automatically deleted.
 - [By amount]**: When the number of stored accounting information exceeds the set number, accounting information is automatically deleted in chronological order with the oldest information deleted first.
- 3) Enter the reference number in the **[Value]** input area.
The timing of automatic deletion is decided in conjunction with the unit selected in step 2.


Checking the System Events Log

A history of events (various kinds of processing) that occurred in the print controller can be checked.



A list of events up until this time is displayed.

- Displayed items: Time, Type, Event class, Details
- To save the event log, click the **[Download]** button, and specify the destination folder and file name to save. The data is saved in CSV file format.
- When you click an event in the list, the **[Remove all older entries]** button is displayed.




- When you want to delete all old entries at once, click the **[Remove all older entries]** button to delete the event.

After the checking is completed, click the **[Close]** button to close the screen.

Checking Accounting Information

A history of job processing performed by the print controller can be checked.



A list of job processing up until this time is displayed.


- Displayed items: Job, Owner name, Modification time, Processing time, Print time, Total page count, Output count, Final status
- When you click an entry in the list, the **[Remove selected entry]** button, the **[Remove all older entries]** button, and the **[Show details]** button are displayed.



[Remove selected entry]: When clicked, the selected entry is removed.

[Remove all older entries]: When clicked, all information prior to the selected entry is removed.

[Show details]: When clicked, the screen switches to the details screen of the selected job. Click the **[Back to overview]** button to return to the list screen.



- To save the account information, click the **[Download]** button, and specify the destination folder and file name to save. The data is saved in CSV file format.

After the checking is completed, click the **[Close]** button to close the screen.

Managing Custom Queue

The administrator can register various settings in the print controller in advance to process jobs sent from the computer as a custom queue. With the registration of frequently used print settings as a custom queue, you can print jobs with the same processing conditions without changing the settings many times, by simply specifying the registered output queue.


Note:

- The processing items that can be set for queues are based on the setting items of the printer driver. [p.92](#)
- For instructions on how to specify the output queue, refer to the separate manual, "Printer Driver Guide".

Creating New Queues [New queue]

- 1 Move the mouse pointer over the [Queue] menu button and then click [New queue] in the displayed sub-menu.**

The Create new queue screen is displayed.



- 2 Enter the name of the new queue in the [Queue name] input area.**

Enter a name up to 12 characters long using alphanumeric characters and symbols (-.^_).


- 3 Select [Queue type].**

[Print]: The job sent to this queue is printed by the printer.

[Hold]: The job sent to this queue is stored in the print controller and will not be printed until a print command is given.

- 4 Click the [Create] button.**

The button of the queue name input in step 2 is added to the Job / Queue selection buttons (on the left side of the screen).



- 5 Set the processing conditions of the queue.**

For processing conditions and setting method, see "Changing Detailed Settings of Queues".

[p.92](#)


Deleting Custom Queues [Delete queue]

- 1 Click the queue button to delete from the Job / Queue selection buttons (on the left side of the screen).



- 2 Move the mouse pointer over the [Queue] menu button and then click [Delete queue] in the displayed sub-menu.

Note:

- After selecting the queue button, the queue can be also deleted by clicking  of the Job / Queue information display (on the right side of the screen) in the state that the job is unselected.

- 3 Click the [Yes] button in the confirmation dialog box.

The selected custom queue is deleted.

Note:

- [Normal] and [Hold] queues cannot be deleted.

Changing Detailed Settings of Queues [Queue details...]

This section describes processing settings of newly created queues and how to change the settings of existing queues.

Note:

- The following settings of **[Normal]** and **[Hold]** queues can be changed.
 - Normal: Queue code, priority, direct port, prechecking setting
 - Hold: Queue code, prechecking setting

1 After selecting a queue button, click  of the Job / Queue information display (on the right side of the screen) in the state that the job is unselected.


A details screen of the queue is displayed.

Clicking the setting group icons at the top of the screen switches the details screen.

Note:

- A details screen of the queue can be also displayed by moving the mouse pointer over the **[Queue]** menu button and then clicking **[Queue details...]** in the displayed submenu.

Queue details screen (Edit screen)



2 Changing queue processing settings.

When you click the icon at the top of the screen, the screen will switch.

[Queue priority]: When placing a checkmark, the settings of queue are prioritized over the settings for the printer driver.

[Ok]: Click to save setting changes and end editing.

[Apply]: Click to save setting changes and continue editing.

[Cancel]: Click to cancel setting changes and end editing.


The processing items that can be set for queues are the same as the setting items for jobs except **[General]** and **[PCL settings]**.

For the settings of the **[General]** screen and the **[PCL settings]** screen, see the next page onward.

For other screens, see “Viewing / Editing Job Details” p.24.

[General] Screen

The outline information and basic settings of queues are displayed.



Information displayed / Settings

1) Name

Displays the name of the queue.

2) Type

Displays the type of queue (Print or Hold).

3) Status*

Displays the current status of the queue (whether or not it has been stopped).

4) Visible in network

When placing a checkmark, the queue is displayed in the network.

To hide the queue display on the network, remove the checkmark.

5) Queue code (1-8 digits)

Set the password of queue if necessary.

When the password is set, the job sent to the queue from the computer can be added to the queue only when the correct password has been input in **[Workflow]** of the printer driver. When the password is incorrect, an error is generated and the job is ended.

For the print settings from the computer, refer to the separate manual, "Printer Driver Guide".

6) Priority*

Sets the priority (low, middle, high) of the queue.

7) Direct port*

Sets the port number (9100-9999) of the RAW port.

8) Number of jobs

Displays the number of jobs in the queue.

9) Number of pages

Displays the total number of pages of the jobs in the queue (the number of pages of each job x the number of copies).

10) Pages (from/to)

Specify the range of pages to be processed "From page" - "To page".

Note:

- To specify all pages, enter "1-0".

11) Copy count

Specifies the number of copies.

12) Queue priority

When placing a checkmark, the settings of queue are prioritized over the settings for the printer driver.

13) Prechecking

Sets the pre-flight (the data check before output and the creation of thumbnails).

[Precheck pages]: Specify the pages to check.

Select **[All]** or enter the last page in **[Up to page]**.

[Create thumbnails]: Set the thumbnails to create.

Select **[All (prechecked)]** or enter the last page in **[Up to page]**


[Thumbnail quality]: Select the image quality of thumbnails from the following five levels.

Very low (fast) / Low / Default (medium) / High / Very high (slow)

* Displayed only when the type of queue is "Print".

[PCL settings] Screen

This screen displays settings concerning PCL job processing.



Settings


- 1) **PCL symbol set**
Select the symbol set (the encoding of character).
- 2) **PCL default font**
Select the PCL font.
- 3) **PCL pitch**
Set the pitch of font (the number of characters in 1 inch).
- 4) **PCL lines per page**
Set the lines per page.
- 5) **PCL point size**
Set the font size for proportional fonts.
- 6) **PCL line termination**
Select the conversion process of linefeed code.
[No change]: Select to print a text file from a Windows computer.
[Add LF after CR]: Select to print a text file from a Macintosh computer.
[Add CR before LF + FF]: Select to print a text file from a UNIX computer.
[Add LF, add CR]: Select to add both "LF" and "CR".
- 7) **PCL line wrapping**
Select whether to use automatic wrapping according to the width of the page or not.
- 8) **PCL default paper size**
Select the paper size to be applied when the information about paper size is not contained in a PCL job.
- 9) **PCL custom paper size**
When **[Custom]** is selected in **[PCL default paper size]**, set the width and the height of paper (mm).
- 10) **Queue priority**
When placing a checkmark, the settings of queue are prioritized over the settings for the printer driver.

Stopping Queue Processing [Stop]

Queue processing can be stopped.

Move the mouse pointer over the **[Queue]** menu button and then click **[Stop]** in the displayed submenu.

Note:


- After selecting the queue button, processing can be also stopped by clicking  of the Job / Queue information display (on the right side of the screen) in the state that the job is unselected.

Resuming Queue Processing [Start]

Processing of a queue that has been stopped can be resumed.

Move the mouse pointer over the **[Queue]** menu button and then click **[Start]** in the displayed submenu.

Note:

- After selecting the queue button, processing can be also resumed by clicking  of the Job / Queue information display (on the right side of the screen) in the state that the job is unselected.

Rebooting the Print Controller

You can reboot the print controller from the RISO Console.

- 1 Move the mouse pointer over the [RIP] menu button and then click [RIP reboot] in the displayed sub-menu.**
- 2 Click the [Yes] button in the confirmation dialog box.**

The print controller will reboot.

Shutting Down the Print Controller

You can shut down the print controller and turn the power off from the RISO Console.

- 1 Move the mouse pointer over the [RIP] of menu button and then click [RIP shutdown] in the displayed sub-menu.**
- 2 Click the [Yes] button in the confirmation dialog box.**

The print controller will shut down.



Using the Included Utility Software

When you execute the setup from the CD-ROM that comes with this product, the following utility software is installed.

Utility Software

◆ RISO Printer Driver (Installer)

Installer for the IS1000C / IS950C printer driver

◆ RISO Management Tool

Utility for setting the IP address of the IS1000C / IS950C on the network and starting the print controller by remote control

◆ SMAP (Windows only)

Direct print utility that allows printing by the dragging and dropping files

This chapter describes the functions and how to operate the RISO Management Tool and SMAP.

Note:

- For software installation, refer to the separate manual, "Setup Guide".
- For information on the RISO Printer Driver, refer to the separate manual, "Printer Driver Guide".

Using the RISO Management Tool

The RISO Management Tool allows the user to easily search the print controller on the network, set IP addresses, and start the print controller from the computer. The RISO Console can also be easily started from the RISO Management Tool.

Note:

- When the IS1000C / IS950C is newly connected to a network, the network settings of the print controller can be made from the RISO Management Tool. For details, refer to the separate manual, "Setup Guide".
- The screens used for this explanation use an IPv4 address.

Starting the RISO Management Tool

For Windows:

From the **[Start]** menu of the Windows computer, select **[All Programs] - [RISO] - [RISO IS1000C IS950C] - [RISO Management Tool]**.


For Windows 8 / Windows 8.1, open the "Apps" screen and click **[RISO Management Tool]** in the **[RISO IS1000C IS950C]** group.

For Windows 10, Select **[Start] - [All apps] - [RISO IS1000C IS950C] - [RISO Management Tool]**.

For Macintosh:

Select **[Applications] folder - [RISO IS1000C IS950C] - [RISO Management Tool]**.

Basic screen



1) Menu

When clicking, the corresponding function is executed. For details, see the next page onward.

2) Language selection

From the language selection box on the right side of the screen, select the language for messages displayed on the RISO Management Tool.

3) Autostart (Windows only)

When placing a checkmark, the RISO Management Tool is set to automatically start when the computer starts. If you do not start RISO Management Tool as an administrator, nothing will be displayed.

4) Exit

Exit the RISO Management Tool.

5) Minimize to tray

When clicking, the screen of the RISO Management Tool is minimized and stored in the task tray.

When clicking the RISO Management Tool icon, the basic screen is displayed.

The RISO Management Tool icon is displayed in the task tray.




When the mouse is moved over the RISO Management Tool icon, the status of all the print controllers added to the RISO Management Tool can be viewed as a popup.

Searching for Print Controllers on the Network

Click **[Search]** on the basic screen of the RISO Management Tool.



The IS1000C / IS950C connected to the network are displayed on the screen.




Note:

- If the computer and the print controllers are not connected to the same network segment, the print controllers will not be found. Add them using the procedure in “Adding Print Controllers to the List” p.101.


Displaying Print Controller Settings

1 On the basic screen of the RISO Management Tool, select the name of a connected controller from the list.



2 Click **[Display]**.


The communication settings screen of the print controller is displayed.




Adding Print Controllers to the List

When the print controller connected to the network cannot be automatically detected, the print controller can be manually added to the list.

- 1 **On the basic screen of the RISO Management Tool, click [Add RIP].**
The communication settings screen is displayed.




- 2 **Enter the “RIP Name” or “IP address” of the print controller you want to add to the list, and click the [Ok] button.**



Note:


- For the “RIP Name” and “IP address”, confirm with your network administrator.

When the relevant print controller is detected, it is displayed in the list.



Deleting Print Controllers from the List

- 1 **On the basic screen of the RISO Management Tool, select the RIP name you want to delete from the list.**




- 2 **Click [Delete RIP].**
The selected RIP name is deleted from the list.

Starting Up Print Controllers


The print controller displayed in the list of the RISO Management Tool can be started from the computer.

1 On the basic screen of the RISO Management Tool, select the RIP name of the sleeping print controller from the list.

2 Click [Wake-Up].




The print controller starts up, and the status is displayed in the list.



Displaying Latest Status

On the basic screen of the RISO Management Tool, click [Refresh].




The latest status of the print controllers displayed in the list is displayed.


Starting Up the RISO Console

From the RISO Management Tool, the status of the printer controller can be checked and the RISO Console that manages jobs and queues can be started.

On the basic screen of the RISO Management Tool, select the target RIP name from the list and click [WWW].



The Web browser starts, and the RISO Console screen for the selected print controller is displayed.



For available functions and operation procedures of the RISO Console screen, see “Basic Operations” p.6 and “Administrator Settings” p.50.

Using SMAP (Windows only)

SMAP allows the user to quickly print files by simply adding the file to SMAP without opening the application software used to create the file. The file is printed at the processing settings registered in the queue of the specified print controller.

Note:

- This software cannot be used with Macintosh computers.


Starting SMAP

From the **[Start]** menu of the Windows computer, select **[All Programs] - [RISO] - [RISO IS1000C IS950C] - [SMAP]**.

For Windows 8 / Windows 8.1, open the “Apps” screen and click **[SMAP]** in the **[RISO IS1000C IS950C]** group.

For Windows 10, select **[Start] - [All apps] - [RISO IS1000C IS950C] - [SMAP]**.


The basic screen is displayed.



When quitting SMAP, click the **[Quit]** button.


Direct Printing by SMAP

- 1 On the basic screen of SMAP, select the print controller (print driver) to send the original data.



On the printer list, the printer drivers installed in your computer are displayed. When installed in the standard way, the printer driver for the IS1000C / IS950C is displayed in the form of “RIP name” - “Queue”.
(Example) IS1000C-Normal / IS950C-Normal


- 2 Click the [Add Files] button.



Note:

- Files can also be added by dragging and dropping them on the SMAP screen.


- 3 Select the file to print, and click the [Open] button.



Note:


- The file formats that can be printed are as follows.
PostScript, PCL, ASCII text, PDF file*, TIFF file
*If RAW port is set for a printer, SMAP cannot be used to print PDF files to that printer.
- To add multiple files, repeat steps 2 and 3.
- To remove the added file, select the file you want to remove from the file list on the basic screen of SMAP, and click the [Remove] button.

- 4 Click the [Download] button.



Using the Included Utility Software

The original data is sent to the specified queue of the print controller, and processing starts.



Dragging and Dropping Files on the SMAP Icon on the Desktop


With the creation of a SMAP shortcut icon on the desktop, direct printing can be executed by simply dragging and dropping files on the shortcut icon.

1 Drag and drop the file to print onto the SMAP icon.



The list of print controllers (printer drivers) is displayed as a popup.

2 Select the print controller (including the queue) to send the original data.



The original data is sent to the specified queue of the print controller, and processing starts.



Appendix

Feature Restrictions


The following restrictions apply to operations performed using a monitor, USB keyboard, or USB mouse that is connected to the IS1000C / IS950C.

Feature Restrictions

| | Feature | Restriction | Page |
|------------------------|--|---|--------|
| General | Mouse operation | When right-clicking, the menu (copy, paste, etc.) is not displayed. | – |
| | (When clicking an icon in the status area) Display printer's console screen | Cannot be displayed | ☞ p.7 |
| | Upload jobs | Cannot be uploaded | ☞ p.11 |
| | Import archive jobs | Cannot be imported | ☞ p.45 |
| | Download printer general information (status report) | Cannot download ([Download] button is not displayed) | ☞ p.46 |
| Administrator Settings | Download print controller general information (status report) | Cannot download ([Download] button is not displayed) | ☞ p.52 |
| | Time setting for print controller | Cannot be set ([Synchronise] button is not displayed) | ☞ p.64 |
| | Backup various print controller settings | Cannot backup ([Backup] is not displayed in upper-right of screen) | ☞ p.66 |
| | Color calibration | Only viewing is available (The [Browse] , [Import calibration] , [Export calibration] , and [Cancel] buttons are not displayed) | ☞ p.80 |
| | Profile management | Only viewing is available ([Upload profile...] and [Delete] buttons are not displayed) | ☞ p.81 |
| | Font management | Only viewing is available (The [Browse] , [Download] , and [Delete] buttons are not displayed) | ☞ p.83 |
| | Save system events log information | Cannot save ([Download] button is not displayed) | ☞ p.87 |
| Save accounting log | Cannot save ([Download] button is not displayed) | ☞ p.88 | |

Troubleshooting

This section describes displayed information and solutions for trouble that occurs while operating the print controller and the RISO Console.

| Trouble | Cause and solution |
|---|--|
| The RISO Console does not start. | The "RIP Name" or "IP address" has not been correctly entered into the URL input area. Check with the administrator, and enter the correct "RIP name" or "IP address". |
| The print results are different from the settings in the printer driver. | In the queue of the print controller through which original data has been sent, the "Queue priority" is set to "on". When you want to prioritize the settings of the printer driver, either change the processing settings of the queue (administrator setting) or select a different queue before executing the print operation. "[General] Screen"  p.93 |
| The job you have sent cannot be cancelled, deleted, or edited in the job manager. | The job manager has been used without logging in or was logged into with an ID that is different from the owner of the job. Log in with the correct ID. |
| Printer status is not displayed properly in the RISO Console. | The performance of the printer and controller is unstable. Turn off the printer and any peripheral devices, then turn them on again. |
| The ERROR lamp lights up during HDD backup. | An error occurred during HDD backup. 1) Delete the backup data file in the [Backup Data List] which has [Error] under [Result] . 2) Reboot the print controller. 3) Perform backup again. |
| The ERROR lamp lights up during restore. | An error occurred during restore. 1) Reboot the print controller. 2) Perform restore again. Important!: <ul style="list-style-type: none"> • If the RISO console screen cannot be displayed, format the hard disk drive via the bootloader menu. • If the print controller does not restart after restore, contact your dealer (or authorized service representative). Note: <ul style="list-style-type: none"> • When an error occurs, fragmented files of failed restores are created. Connect the external hard disk drive to a computer and delete these files. |

Index

A

| | |
|--------------------------------|-------|
| Accounting Information | 88 |
| Administrator | 9, 50 |
| Annotation | 32 |
| Append | 31 |
| Archived Jobs | 37 |
| ASCII printing | 60 |
| Authentication Algorithm | 56 |
| Auto logout time | 65 |
| Auto-reducing | 27 |

B

| | |
|-------------------------------|----|
| Back cover | 29 |
| Backup | 66 |
| Barcode area | 78 |
| Barcode Area Definition | 30 |
| Barcode Area Proof | 30 |
| Basic | 25 |
| Binding margin | 27 |
| Booklet cover | 29 |
| Booklet fold mode | 29 |
| Brightness | 30 |

C

| | |
|--|--------|
| Canceling a Job | 22 |
| Changing Detailed Settings of Queues | 92 |
| Changing Passwords | 59 |
| CIE | 35 |
| CMYK | 35 |
| Collate | 28 |
| Color | 35 |
| Color calibration | 80 |
| Color output mode | 25, 30 |
| Comment | 34, 52 |
| Communication settings | 53 |
| Console Screen | 6 |
| Consumables | 48 |
| Continuous output | 28 |
| Contrast | 30 |
| Copy count | 26 |
| Copying a Job | 21 |
| Create new queue | 90 |
| Creating Archived Jobs | 14 |
| Custom forms | 75 |
| Custom paper sizes | 76 |
| Custom Queue | 90 |

D

| | |
|---|----|
| Default page size | 60 |
| Deleting a Job | 22 |
| Deleting backup data | 73 |
| Deleting Custom Queues | 91 |
| Destination | 34 |
| Detailed information | 52 |
| Detailed Settings of the Print Controller | 51 |

| | |
|-------------------------------------|----|
| Details for security policies | 56 |
| DeviceLink | 35 |
| DH Group | 56 |
| Domain | 54 |
| Duplex | 27 |

E

| | |
|-------------------------------|----|
| Editing a Job | 24 |
| Editing Archived Jobs | 37 |
| Enable Subset Finishing | 29 |
| Encryption Algorithm | 56 |
| Enforce https | 54 |
| Engine IP Configuration | 54 |
| Ethernet address | 54 |
| EtherTalk zone | 54 |
| Event log | 87 |
| Export archive jobs | 44 |

F

| | |
|-----------------------------------|----|
| Finishing | 29 |
| Finishing side | 29 |
| Font | 32 |
| Font management | 83 |
| Font size | 32 |
| Form 1 (all pages or front) | 31 |
| Form 2 (back) | 31 |
| Forms | 31 |
| Front cover | 29 |
| Front/Back separately | 31 |

G

| | |
|--------------------------------|----------------|
| General | 26, 46, 52, 93 |
| General user | 9 |
| Generate Job Info Events | 60 |
| Guest user | 9 |

H

| | |
|----------------------------------|----|
| Hash Algorithm | 56 |
| HDD backup | 69 |
| Header page | 29 |
| Hold queue | 18 |
| Horizontal shift | 33 |
| Horizontal shift back side | 33 |
| Hotfolder | 13 |

I

| | |
|---|--------|
| Icons | 8 |
| IKE mode | 56 |
| Image | 30 |
| Image rotation | 27 |
| Image shift | 33 |
| Importing an Archived Job from the Computer | 45 |
| Imposition | 27, 29 |
| Imposition direction | 27 |
| Input tray | 25, 28 |
| Insert font | 32 |

| | | | |
|---|--------|---------------------------------|--------|
| Insert page number | 32 | Output profiles | 35 |
| Insert total pages | 32 | Output size | 27 |
| Installable options | 47 | Output tray | 28 |
| IPv4 | 54 | Output trays | 47 |
| IPv6 | 54 | Owner | 26 |
| J | | P | |
| Job / Queue information display | 7 | Page size | 25, 27 |
| Job / Queue selection button | 7 | Pages | 26 |
| Job auto delete | 60 | Pages to print | 26, 52 |
| Job count | 52 | Paper trays | 46 |
| Job delegation | 34, 62 | Paper type | 25, 28 |
| Job Display Order | 23 | Password | 58 |
| Job manager | 20 | PC name | 26 |
| Job name from file name | 60, 61 | PCL settings | 94 |
| Job ownership | 20 | PCL tray mapping | 77 |
| Job Preview | 23 | PostScript output | 36 |
| Job settings | 60 | Prechecking | 26 |
| Job splitting | 34 | Prepend job | 31 |
| K | | Pre-shared Key | 56 |
| Keyboard | 108 | Print and pause | 34 |
| L | | Print density | 30 |
| Layout | 27 | Print face | 31 |
| Lifetime | 56 | Print first page only | 32 |
| Line smoothing | 30 | Print pages | 26 |
| Log in | 9, 50 | Print pattern | 31 |
| Log settings | 85 | Print position | 33 |
| Logging | 36 | Print start page | 32 |
| Login ID | 58 | Printer Status | 46 |
| Login information input area | 7 | Printing Archived Jobs | 15 |
| M | | Priority layer | 31 |
| Mail server | 54 | Profile management | 81 |
| Max drops | 35 | Punch mode | 25, 29 |
| Menu | 7 | Pure black | 35 |
| Merging Multiple Archived Jobs | 41 | Q | |
| Merging Pages from Multiple Archived Jobs | 42 | Queue | 18 |
| Message display area | 7 | Queue priority | 94 |
| Mixed output size | 27 | Quick print settings | 25 |
| Monitor | 108 | R | |
| Mouse | 108 | Rebooting | 96 |
| Moving a Job to Another Queue | 21 | Registering New Users | 58 |
| Multi-up | 27 | Rendering intent | 35 |
| N | | Reports | 84 |
| Name | 26 | Resolution | 30 |
| Name server | 54 | Restore | 71 |
| NetBIOS workgroup | 54 | Resuming Queue Processing | 95 |
| Normal queue | 18 | Reverse order | 28 |
| O | | RGB | 35 |
| Offset output pages | 29 | RIP Data | 37 |
| Orientation | 25, 27 | RIP name | 54 |
| Others can see jobs | 59 | RIP status | 52 |
| Output face | 28 | RISO Console Screen | 7 |
| | | S | |
| | | Saving Archived Jobs | 43 |

Index

| | |
|--|--------|
| Scale to fit | 27 |
| Scope (IPv4) | 56 |
| Scope (IPv6) | 56 |
| Screen width | 30 |
| Screening | 30 |
| Screensaver | 65 |
| Secure print | 34 |
| Selecting Languages | 49 |
| Send E-mail | 34 |
| Sender address | 54 |
| Separate books | 29 |
| Shift front/back separately | 33 |
| Shutting Down the Print Controller | 96 |
| Simplex Print Speed Priority | 29 |
| Slip sheet | 28 |
| Slip sheet tray | 28 |
| SMAP | 104 |
| Source | 26 |
| Staple mode | 25, 29 |
| Start number | 32 |
| Status | 26 |
| Status display area | 7 |
| Status report | 52 |
| Stopping Queue Processing | 95 |
| System Events Log | 87 |
| T | |
| Time settings | 64 |
| Transparency | 32 |
| Tray selection per page | 28 |
| Trays | 28 |
| Type | 26 |
| U | |
| User defined sizes | 76 |
| User management | 58 |
| V | |
| Vertical shift | 33 |
| Vertical shift back side | 33 |
| W | |
| Workflow | 34 |
| Z | |
| Zoom | 27 |

RISO

Please contact following for supplies and service: